SONY

REMOTE CONTROL PANEL

RCP-3730 RCP-3731





OPERATION AND MAINTENANCE MANUAL 1st Edition (Revised 3) Serial No.10001 and Higher Warning—This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

Important—To insure that the complete system (including this peripheral) is capable of complying with the FCC requirements, it is recommended that the user make sure that the individual equipment of the complete system has a label with one of the following statements.

"This equipment has been tested with a Class A Computing Device and has been found to comply with Part 15 of FCC rules."

-or-

"This equipment complies with the requirements in Part 15 of FCC rules for a Class A Computing Device."—or equivalent.

The shielded interface cable recommended in this manual must be used with this equipment in order to comply with the limits for a computing device pursuant to Subpart J of Part 15 of FCC rules.

For the customers in Canada

This apparatus complies with the Class A limits for radio noise emissions set out in Radio Interference Regulations.

Pour les utilisateurs au Canada

Cet appareil est conforme aux normes Classe A pour bruits radioélectriques, spécifiés dans le Règlement sur le brouillage radioélectrique.

このマニュアルに記載されている事柄の著作権は当社にあり、説明内容は機器購入者の使用を目的としています。 従って、当社の許可なしに無断で複写したり、説明内容(操作、保守等)と異なる目的で本マニュアルを使用することを禁止します。

The material contained in this manual consists of information that is the property of Sony Corporation and is intended solely for use by the purchasers of the equipment described in this manual.

Sony Corporation expressly prohibits the duplication of any portion of this manual or the use thereof for any purpose other than the operation or maintenance of the equipment described in this manual without the express written permission of Sony Corporation.

Le matériel contenu dans ce manuel consiste en informations qui sont la propriété de Sony Corporation et sont destinées exclusivement à l'usage des acquéreurs de l'équipement décrit dans ce manuel.

Sony Corporation interdit formellement la copie de quelque partie que ce soit de ce manuel ou son emploi pour tout autre but que des opérations ou entretiens de l'équipement à moins d'une permission écrite de Sony Corporation.

Das in dieser Anleitung enthaltene Material besteht aus Informationen, die Eigentum der Sony Corporation sind, und ausschließlich zum Gebrauch durch den Käufer der in dieser Anleitung beschriebenen Ausrüstung bestimmt sind.

Die Sony Corporation untersagt ausdrücklich die Vervielfältigung jeglicher Teile dieser Anleitung oder den Gebrauch derselben für irgendeinen anderen Zweck als die Bedienung oder Wartung der in dieser Anleitung beschriebenen Ausrüstung ohne ausdrückliche schriftliche Erlaubnis der Sony Corporation.

目次 TABLE OF CONTENTS

1. 取り扱い操作	2. 設置		
1-1. 概要1-1 (J)	2-1. 開梱と再梱包	2-1	(J)
1-1-1. 主な特長1-1 (J)	2-2. 標準附属品	2-2	(J)
1-1-2. ファイルシルテムについて1-4 (J)	2-3. 適合コネクター/ケーブル	2-3	(J)
1-2. 各部の名称と働き1-6 (J)	2-3-1. コネクターの入出力信号	2-3	(J)
1-3. 起動と初期調整1-13(J)	2-3-2. 接続コネクター		
1-3-1. 起動1-13(J)	2-4. 設置使用環境		
1-3-2. 初期調整1-14(J)	2-5. 設置スペース		
1-3-3. IDコードの設定1-16(J)	2-5-1. 設置条件		
1-4. 操作1-19(J)	2-5-2. 外形寸法		
1-4-1. ファンクション選択スイッチ操作1-20(J)	2-5-3. コンソールへの取り付け方法		
1-4-2. 手動調整1-33 (J)	2-6. 基板内スイッチの機能		
1-4-3. アイリスとマスターブラックの調整1-36(J)	2-7. システム接続		
1-4-4. ファイル操作1-39(J)	2-7. クバノ 4 3女形) (3)
1-4-5. LCDメッセージ一覧1-51(J)	2. INSTALLATION		
1-4-5. 仕様1-51(J)			
1-5. 任依1-33(J)	2-1. Packing and Unpacking	2-1	(E)
1. OPERATION	2-2. Supplied Accessories		
1. OPERATION	2-3. Connectors and Cables		
1-1. Overview1-1 (E)	2-3-1. Connector Input/Output Signals		
1-1-1. Features	2-3-2. Connectors		
1-1-2. File System1-3 (E)	2-4. Operating Environment 2-5. Installation Space		
1-2. Location and Function of Parts and Controls1-5 (E)	2-5-1. Installation Conditions		
1-3. Start-up and Initial Adjustment1-12 (E)	2-5-2. Outside Dimensions		
1-3-1. Start-up	2-5-3. Installation to Console		
1-3-2. Initial Adjustment1-13 (E) 1-3-3. ID Code Setting1-15 (E)	2-6. Function of Switches on PC Board		
1-3-5. ID Code Setting1-15 (E) 1-4. Operation	2-7. System Configuration	2-10) (E)
1-4-1. Function Select Switch Operation1-19 (E)			
1-4-2. Manual Adjustment1-31 (E)	3. サービスインフォメーション		,
1-4-3. Iris and Master Black Adjustment1-34 (E)			
1-4-4. File Operation	3-1. 主要部品の交換方法		
1-4-5. Messages Displayed on the LCD1-49 (E) 1-5. Specifications1-51 (E)	3-1-1. 外装の外し方		(J)
1-3. Specifications1-31(E)	3-1-2. ジョイスティックボリュームの交換		
	(RCP-3730のみ)	3-2	(J)
	3-1-3. コントロールパネルの外し方	3-3	(J)
,	3-2. サービス上の注意事項	3-4	(J)
	3-2-1. PROM IC	3-4	(J)
	3-2-2. 補修用部品の注意事項	3-4	(J)
	3-2-3. 治工具		
	3-2-4. チップ部品交換時の注意事項		
	3. SERVICE INFORMATION	•	
	2.1 Paulanament of Maria Paul		(P)
	3-1. Replacement of Main Parts		
	3-1-1. Cabinet Removal	3-1	(E)
	(only for RCP-3730)	3-2	(E)
	3-1-3.Removal of Control Panels	3-3	(E)
	3-2. Note on Maintenance Services	3-4	(E)
	3-2-1. PROM IC		
	3-2-2. Note on Replacement Parts		
	3-2-3. Fixture		
	3-2-4. Repracement of Chip ratis	ر-د	(11)

A.	DIAGRAMS	94 kg
	Board Layout	A-1
	Board Layout	A-5
	Frame (1/2)	
197	MPU-56	
	Frame (2/2)	
	DSP-27, DSP-28, IR-12, LED-112, SW-402	2A-17
В.	SEMICONDUCTOR PIN ASSIGNI	MENTS
C.	SPARE PARTS	
	Parts Information	
	Exploded View	
	Screws	
	Electrical Parts List	
	Packing Materials & Supplied Accessories.	

第1章 取り扱い操作

1-1. 概要

リモートコントロールパネルRCP-3730/3731は、3板式CCDカラービデオカメラBVP-370/270の調整機能を、カメラコントロールユニットCCU-370を介してリモートコントロールするためのコントロールパネルです。本機は、専用のケーブルでCCU-370に接続することにより、CCU-370から最大200m離して使用することができます。

RCP-3730とRCP-3731は機能的には同一ですが、アイリス/マスターブラック調整部が、 RCP-3730ではジョイスティックタイプ、RCP-3731ではつまみになっています。

1-1-1. 主な特長

本機の主な特長は次の通りです。

高い操作性

本機の操作ボタン、調整つまみなどは、機能別に、使う頻度を考慮してパネル上に配置されています。また、自照式ボタンの点滅や点灯の状態により、操作状況がわかるようになっています。さらに、誤操作した場合にカメラの動作やセットアップに重大な影響を及ぼすボタンの周囲にはガードを付けるなど、さまざまな機能を簡単に、そして間違いなく操作できるように工夫されています。

LCD(液晶表示)による操作関連情報の表示

調整中の項目、ファイル情報、操作進行のための情報、カメラシステムからのメッセージなどを液晶パネルにより表示します。システムの現在の状態が一目で分かります。

オートセットアップ機能

マイクロコンピューターにより、各調整項目を自動的に調整するオートセットアップ機能を備えています。セットアップ調整項目の一括自動調整や、ホワイトレベルまたはブラックレベルのみの自動調整が可能です。

リファレンスファイル機能

各調整項目を自動調整する際の基準値は、あらかじめカメラヘッド内に設定されていますが、本機の操作により新たな基準値を設定し、リファレンスファイルとしてカメラヘッド内に保管することができます。

セットアップファイル機能

撮影条件に合わせた調整値をセットアップファイルとしてカメラヘッド内に保管しておき、必要なときに呼び出して、同じ状況を簡単に再現することができます。セットアップファイルは、最大8個まで作成できます。

シーンファイル機能

撮影シーンに合わせてペインティングなどの操作により調整したデータを、シーンファイルとしてカメラヘッド内に保管しておき、必要なときに呼び出して、シーンに合った撮影条件を簡単に再現することができます。シーンファイルは、セットアップファイル1~8に対して各8個(合計64個)まで作成できます。

ファイルセキュリティ機能

リファレンスファイルとセットアップファイルに関しては、特定のIDコードを使わない と保管操作を行えないようにすることができます。これにより、特定の人以外によるファイルの保管や書き換えを禁止することができます。

カメラのシャッター機能をコントロール

本機上での操作により、CCDカメラの電子シャッター機能のオン/オフ切り換え、およびシャッタースピードの6段切り換えを行うことができます。

デジタル回線による接続

カメラコントロールユニットと本機との間は、デジタル回線により信号の受け渡しを行います。1本の接続ケーブル (CCA-2) ですべての信号の授受を確実に行うことができます。

マスターセットアップユニットとの同時コントロールが可能

本機とマスターセットアップユニットMSU-350との同時コントロールが可能です。同時コントロールのモードはパラレル(並行)、スプリット(分担)の2種類があります。本機側では、パラレルモードのときは全機能、スプリットモードのときは絞りとマスターブラックの調整機能を使用できます。

ベータカムカメラのコントロールも可能

本機をカメラコントロールユニットCCU-350/355に接続すれば、カメラアダプターを取り付けたベータカムシリーズカメラ (BVP-7/50/70/7000HSなど) もコントロールできます。

19インチのラックに4台取り付け可能

本機は、19インチのEIA標準ラックに4台並べて取り付けることができます。(高さは7ユニット)

本機は、CCDカラービデオカメラ専用のリモートコントロールパネルです。 撮像管式カメラのコントロールはできません。

1-1-2. ファイルシステムについて

BVP-370シリーズのビデオカメラは、調整したデータを次の3種類のファイルとして、カメラヘッドに保管する機能を備えています。

- 1. リファレンスファイル
- 2. セットアップファイル。
- 3. シーンファイル

ファイルの保管や呼び出しは、マスターセットアップユニットMSU-350やリモートコントロールパネルRCP-3720/3721/3730/3731等を使って行います。コントロールに使用するパネルによって、取り扱うことのできるファイルの種類や数が異なります。また、ビデオカメラのタイプによっては、ファイルに保管できない調整項目もあります。詳しくは、各機種の取り扱い説明書をご覧ください。

1. リファレンスファイル

オートセットアップ調整を行う際の基準となる値を保管しておきます。オートセットアップを実行すると、各項目の値がリファレンスファイルの値に一致するように自動調整されます。したがって、このファイルはすべてのファイルシステムの基準となります。 工場出荷時に基準値はあらかじめ設定されていますが、通常使用する基準値が工場設定値と異なる場合、手動調整によって基準値を新たに設定し、その値をリファレンスファイルとして保管します。

リファレンスファイルに保管されているデータは、新たな基準値が設定および保管されるまで保持されます。

2. セットアップファイル

撮影の条件に合わせて手動調整したセットアップ調整値を保管しておきます。たとえば、 屋内や、屋外での撮影用としてあらかじめ調整したデータに番号(ファイル番号)を付 け、ファイルとして保管しておきます。実際に撮影を始めるときは、その条件に合った ファイルを呼び出せば、カメラシステムは保管されていたデータに従って自動的に調整 され、直ちに撮影を開始することができます。

セットアップファイルに保管されているデータは、新たなデータ保管が行われるまで保持されます。

セットアップファイルは合計8個まで作成することができます。

3. シーンファイル

撮影シーンに合わせてペインティングしたデータを保管しておきます。

たとえば、リハーサル時に特定のシーンに合わせて設定した値をシーンファイルに保管 しておき、本番時にそのファイルを呼び出せば、リハーサル時とまったく同じ状況を再 現することができます。

シーンファイルに保管されているデータは、新たなデータ保管が行われるまで保持されます。

シーンファイルは、各セットアップファイルに対応して8個まで(セットアップファイル 8個に対して合計64個まで)作成することができます。


ファイルに保管できるデータ

○:保管可能 -:保管不可

項目	リファレンス ファイル	セットアップ ファイル	シーン ファイル	調整値 の範囲(%)*
アナログデータ				
R、G、B ホワイトバランス			0	
R、G、B バーティカル モジュレーション				-99~+99
R、G、Bフレアバランス	0			39. 133
ディテイルレベル				
ディテイルリミッター		(a.). (1)		
クリスプニング				0~+99
R、G、B ブラックバランス	〇 (Gのみ)		0	
R、G、Bガンマバランス				
マスターガンマ				-99~+99
マスターニーポイント				
マスターニースロープ				
マスターブラック				
スイッチデータ				
MASTER GAIN			0	-
TEST1 ON			·	
TEST2 ON				
SHUTTER SPEED		,		
FILTER DATA				
DETAIL ON	"			
MATRIX ON				
AUTO KNEE ON		0		
GAMMA SELECT				
GAMMA ON/OFF				

^{* 1-33 (}J) ページ参照。

1-2. 各部の名称と働き



タリー部

-カメラ番号表示

本機に接続したカメラと同じ番号のナン バープレート(付属)を、ここに取り付け ます。

グリーンタリーランプ カメラにグリーンタリー信号が入力され ると点灯します。

ランプ カメラヘッドヘタリー信号を送出すると き押して点灯させます。また、カメラにレ ッドタリー信号が入力されると点灯しま す

-CALL(コール)ボタン兼レッドタリー


ファンクション選択スイッチ操作 部① (1-20 (J) ページ)

SELECT (セレクト) ボタン、▶ (グリー ンランプとオレンジランプ)

ファンクション選択スイッチ操作部②の各ボタンをMASTER GAIN (マスターゲイン)/SHUTTER(シャッタースピード)/ND(NDフィルター)/CC(色温度変換フィルター)ボタンとして使用する(グリーンランプを点灯させる)か、AUTO SETUP(オートセットアップ)/GAMMA(ガントロール)/SYSTEM(システムコマンド)ボタンとして使用する(オレンジランプを点灯させる)かを切り換えます。

ご注意

ファンクション 選択スイッチ 操作部②のボタンが点灯していると、SELECTボタンで切り換えることができません。 一度消灯させてください。



−ファンクション選択スイッチ操作 部② (1−20 (J) ページ)

MASTER/SHUTTER/ND/CCボタン(グリーンランプ点灯時)

各ボタンを押して点灯させると、LCDや数字キーを使って、マスターゲイン/シャッタースピード/NDフィルター/CCフィルターの設定が行えます。

AUTO SETUP/GAMMA/SWITCH/SYS-TEMボタン(オレンジランプ点灯時)

各ボタンを押して点灯させると、LCDや 数字キーを使って、オートセットアップ/ ガンマ/スイッチコントロールのON/ OFFおよびシステムコマンドの実行が行 えます。

ND/CC CTLランプ

ND/CCボタンによる操作で点灯させると、本機からND/CCフィルターの設定ができるようになります。

(点灯から消灯への切り換えは、カメラ 側でしか行えません。)

ご注意

ファイル操作をしたいときは、点灯しているファンクション選択スイッチ操作部 ②のボタンを消灯させてください。 RCP-3730

LCD調整部·

CONTRAST (コントラスト) 調整ねじ LCDのコントラストを調整します。

BRIGHT (明るさ) 調整ねじ LCDの明るさを調整します。

数字入力部-

ファンクション選択ボタンによる操作のための設定や、セットアップファイル/シーンファイルの番号を入力するときに使用します。



-ファイル操作部 (1-38 (J) ページ) 次のような機能の実行に使用します。

SETUP (セットアップファイル) ボタン セットアップファイル操作(保管、呼び出 し)

SCENE(シーンファイル)ボタン シーンファイル操作(保管、呼び出し)

STORE (ストア) ボタン リファレンスファイル/セットアップファイル/シーンファイルの保管およびID コードの登録

CANCEL(キャンセル)ボタン オートセットアップ/IDコード登録/ファイル操作の取り消し

NEXT (ネクストシーンファイル) ボタン: LCDに ↓ で示されているシーンファイル の呼び出し

RECALL(ファイルリコール)ボタン セットアップファイル/シーンファイル の呼び出し RCP-3730

LCD (液晶表示) (1-19(J)ページ) カメラの設定状態、ファンクション選択 ボタンによる操作やファイル操作に必要な情報、各種メッセージなどを表示しま

手動調整部 (調整項目選択ボタン)・ (1-32 (J) ページ)

押して点灯させ、調整項目を選びます。

WHITE (ホワイトバランス): R/G/B ホ ワイトバランス

BLACK (ブラックバランス): R/G/B ブ ラックバランス

FLARE (フレア): R/G/B フレアバラン

GAMMA(ガンマ): R/G/B ガンマバラン

DETAIL (ディ**テイル**): ディテイルレベル/ディテイルリミッター/クリスプニン

KNEE(ニー): マスターガンマ/マスター ニーポイント/マスターニースロープ

V MOD (V モジュレーション): R/G/B バーティカルモジュレーション

PHASE (フェーズ): SC/H 位相

SONY F TALLY ... PAPA JAIL . PANEL ACTIVE госк CTAL NO -- -CC Ta e a FILE OP NEXT TECAL 866 2 3 4 0 5 6 7 8 9. RELATIVE MASTER BLACK REMOTE CONTROL PANEL

CLEAR(クリアー)ボタン 選択された項目の手動調整値をクリアー します。

OFFSET(オフセット)ボタン

選択された項目の、本ボタンを押して点 灯させたときの調整値に対する相対調整 量を、LED表示器に表示させます。

LED表示器

選択された項目の調整値、または相対調 整量を表示します。

調整つまみ

選択された項目の手動調整に使用します。

アイリス/マスターブラック調整部(RCP-3730)(1-35(J) ページ)

RELATIVE

-6#

MASTER BLACK

REMOTE CO

VITROL PANEL

IRIS COARSE (アイリス粗調整) つまみ-絞りの手動調整範囲のおおよその中心値 を定めます。

AUTO IRIS (オートアイリス) ボタン一 絞りの調整を手動から自動に切り換えます。

RELATIVE(相対値モード)ボタンレンズの絞りとマスターブラックの調整を、絶対値モードから相対値モードに切り換えます。

EXTENDER (エクステンダー) ランプー レンズエクステンダーをカメラに挿入す ると点灯します。

MASTER BLACK (マスターブラック) 表示部 マスターブラックの調整値をパーセント で表示します。

IRIS (アイリス) 表示部 絞りの設定値をFナンバーで表示します。 レンズを絞り切る(クローズする)と 「CL」と表示されます。 RCP-3730


ーSENS (アイリス手動調整範囲) 調整ねじ 絞りの手動調整範囲の幅を設定します。

マスターブラックインジケーター マスターブラック調整リングと一緒に回 転して、マスターブラックのおおよその 調整値を示します。

-IRIS (アイリス) 調<u>整</u>レバー兼プレビュー ノブ

スロット方向に動かして絞りの手動調整や、自動調整の微調整(±1F)を行います。映像をモニターしたいときは、軸方向に押して、プレビュー信号をPREVIEWコネクターから出力させます。


-マスターブラック調整リング マスターブラックの手動調整に使用しま す.



IRIS調整レバー調整ねじ IRIS調整レバーのスロット方向の動きの 固さを調整します。

アイリス/マスターブラック調整部 (RCP-3731) (1-35 (J) ページ)

RCP-3731



-RCP-3730の項をご覧ください。


PREVIEW (プレビュー) ボタン映像をモニターするために、プレビュー 信号をPREVIEWコネクターから出力させるとき、押して点灯させます。

MASTER BLACK (マスターブラック) 調・

整つまみ マスターブラックの手動調整に使用しま

iRIS(アイリス)調整つまみ 絞りの、手動調整または自動調整値の微 調整に使用します。

コネクターパネル



PREVIEW (プレビュー) コネクター (6ピン)


プレビュー信号の出力と、PREVIEWボタン(RCP-3731)点灯用電源の入力を、ビデオスイッチャーなどとの間で行います。

ーCCU(カメラコントロールユニット) コネ クター(16ピン) カメラコントロールユニットのRCPコネ クターに接続します。

1-3. 起動と初期調整

1-3-1. 起動

本機は、CCUコネクターに接続したカメラコントロールユニットから電源の供給を受けます。



本機を使ってカメラシステムをコントロールするには、PANEL ACTIVEボタンを押して 点灯させます。


PANEL ACTIVEボタン、PARAボタンの状態と操作可能なボタン/コントロールの関係は 次の通りです。

ボタンの状態		操作可能なボタン/コントロール	
PANEL ACTIVE	PARA*1	TATE OF THE STATE	
	点灯	すべてのボタン/コントロール*2	
点灯	点滅	アイリス/マスターブラック調整部のみ	
	消灯	PARAボタンを除くすべてのボタン/コントロール*2	
	点灯		
消灯*3	点滅	PANEL ACTIVE、LOCK、RELATIVE、ファンクション 選択ボタン**	
	消灯	ASUNCAL Z	

- *1 PARAボタンはマスターセットアップユニット側の同時コントロールのための設定に応じて、点灯 (パラレルモード)、点滅 (スプリットモード) または消灯 (同時コントロール解除) します。本機 側からは、点灯中に押して消灯させることのみ可能です。
- *2 LOCKボタンを押して点灯させると、アイリス/マスターブラック調整部、CALLボタンおよびLOCK ボタン以外のスイッチやコントロールは、働かなくなります。
- *3 PANEL ACTIVEボタン消灯時は、本機によりカメラシステムをコントロールすることはできませんが、操作可能なボタンを使用して設定状態を確認することができます。
- *4 数字キーによる入力は行えません。

1-3-2. 初期調整

位相調整



位相調整を行いたい箇所に波形モニターおよびベクトルスコープを接続して、次の手順によりH位相とSC位相を合わせます。

- **1** PANEL ACTIVEボタンを押して点灯させます。
- 2 CAM PWボタンを押して点灯させます。

3 調整項目選択ボタンのPHASEを押して点灯させます。

LCDの4行目に「SC 〈〈 PHASE 〉〉 H」と表示され(下図参照)、同時に、SC位相とH位相の値が、3つのLED表示器のうちの左右の2つにそれぞれ表示されます。 SC位相は -180° から $+180^\circ$ の範囲で度数表示され、H位相は調整範囲に対する割合($-99\%\sim+99\%$)が表示されます。

(LCDの表示例)

- 1、2行目の表示内容はカメラの状態によって異なります。
- **4** 波形モニター、ベクトルスコープを見ながらLED表示器の下の調整つまみを回して、H位相とSC位相を基準信号に合わせます。

1-3-3. IDコードの設定


リファレンスファイルおよびセットアップファイルの保管操作には、非当事者による誤操作防止のため2桁(01~99)のIDコードを適用することができます。

IDコードは次の2通りの方法で設定することができます。

- ●DIPスイッチS2による設定
- ●SYSTEMボタンによる設定

DIPスイッチS2で設定したIDコードは、SYSTEMボタンを使って設定したIDコードに優先します。(出荷時、DIPスイッチS2は「00」に設定されています。)


DIPスイッチS2によるIDコードの設定方法



IDコードの位	スイッチ番号(*)	設定	設定値	ID=-F
	1 (2°=1)	OFF		
100	2 (21=2)	ON	2+4=6	
1の位	3 (2 ² =4)	ON .		
	4 (2³=8)	OFF		36
	5 (2°=1)	ON		30
10の位	6 (21=2)	ON	1+2=3	
	7 (2 ² =4)	OFF		
	8 (2³=8)	OFF		

^{*}各スイッチの表す10進値

下記の手順により、IDコードを登録したり、すでに登録されているIDコードを変更したりすることができます。



- **1** SELECTボタンを押してオレンジのランプを点灯させます。(すでに点灯している場合は、そのままステップ**2**に進みます。)
- **2** SYSTEMボタンを押して点灯させます。 LCDの表示が入力待ち表示に変わります。 (表示例)

0 = ALL PAINT CLEAR 1 = TEST 1/2 SELECT → 1 2 = ID REGISTRATION 3 = SCENE FILE DELETE

3 数字キーで「2」を入力します。 LCDの表示がIDコード入力待ち表示に変わります。 (IDコード登録のための入力待ち表示)

ID REGISTRATION

NEW ID CODE ?

4 数字キーを使って、「00」以外の2桁のIDコードを入力します。 入力したIDコードがLCDに表示されます。 (表示例)

ID REGISTRATION

NEW ID CODE 99

5 STOREボタンを押します。 入力したIDコードが内部メモリーに登録され、LCDに確認表示が現れます。 (表示例)

ID REGISTRATION

NEW ID CODE 99 Store

約5秒後に、LCDはステップ2の入力待ち表示に戻ります。

ご注意

●IDコードとして「OO」を入力したり、IDコードを入力せずにSTOREボタンを押すと、 登録されていたIDコードが消去され、LCDの4行目に「ID code erased」と表示され ます。

ID REGISTRATION

NEW ID CODE ? Store ID code erased

約5秒後に、LCDはステップ2の入力待ち表示に戻ります。


- ●SYSTEMボタンで登録したIDコードを使うためには、DIPスイッチS2のすべてのビットをオフ (「OO」) にしてください。
- ●IDコードの登録を取りやめる場合は、STOREボタンを押す前にCANCELボタンを押します。LCDの表示がステップ2の入力待ち表示に戻ります。

1-4. 操作

LCDの表示について

通常表示

通常、LCDは1行目と2行目にカメラの設定状態、4行目に現在選択されている調整項目名を表示しています。



他機の操作による表示の変化


本機操作時はLCDの表示内容が変化しますが、下記の場合のように、本機以外での操作 やエラー検出によっても表示内容が変化します。

- ●他機(マスターセットアップユニットなど)からオートセットアップまたはリファレンスファイルの保管が実行されると、本機のLCDはそれらの操作の進行状況を表示します。操作が終了すると、LCDは終了メッセージ「Completed!」を約5秒間表示した後に、元の画面に戻ります。
- ●カメラまたはカメラコントロールユニットの自己診断によりエラーが検出されると、本機のLCDの3行目にその内容が表示され(ファンクション選択ボタン点灯時は除く)、CANCELボタンが点滅します。

1-4-1. ファンクション選択スイッチ操作

ファンクション選択ボタンを使って実行できる機能は次の通りです。

ファンクション 選択ボタンの 表示	実行可能な機能		
(上/下)	グリーンランプ点灯時	オレンジランプ点灯時	
MASTER GAIN/ AUTO SETUP	マスターゲインの設定 (1-22 (J) ページ)	オートセットアップ(1-24 (J) ページ)とリファレンス ファイル保管(1-27 (J) ペー ジ)	
SHUTTER/ GAMMA	シャッタースピードの設定 (1-22 (J) ページ)	ガンマ値の設定 (1-29 (J) ページ)	
ND/ SWITCH	NDフィルターポジションの 設定 (1-23 (J) ページ)	カメラ内蔵回路のオン/オフ 切り換え (1-30 (J) ページ)	
CC/ SYSTEM	CCフィルターポジションの 設定 (1-23 (J) ページ)	特殊ファンクションの実行 (1-31 (J) ページ)	



1 SELECTボタンを押して、グリーンまたはオレンジのランプを点灯させます(すでに 点灯している場合は、そのままステップ2に進みます)。

ご注意

SELECTボタンは、ファンクション選択ボタンのどれかが点灯していると働きません。点灯しているボタンを押して消灯させてから、SELECTボタンを押してください。

- 2 実行したい機能のボタンを押して点灯させます。 LCDが通常表示から入力待ち表示に変わります(表示例は後述の各操作手順の説明 参照)。点灯したボタンをもう一度押すと消灯し、LCDは通常表示に戻ります。
- 3 LCDの表示に従って、数字キーで希望の値を入力します。

ご注意

- ●ファンクション選択ボタンのどれかが点灯しているときは、矢印のランプ (グリーンランプまたはオレンジランプ)が示している項目以外の操作は行えません。他の操作を行うには、点灯中のファンクション選択ボタンを押して消灯させてください。
- ●操作を途中でキャンセルしたいときは、CANCELボタンを押します。

- 1 SELECTボタンを押してグリーンのランプを点灯させます。
- **2** MASTER GAINボタンを押して点灯させます。 LCDの表示が入力待ち表示に変わります。

SS: 1000 SET = 2 SCN242 + 18dB ND = 1 CC = A \ 243 MASTER GAIN ?

3 数字キーを使って希望のマスターゲイン値を入力します。

0: 0dB

9:+9

3: +3

(表示例)

18:+18 (1に続けて8を入力します)

6: +6

(表示例)

マスターゲイン値が入力されると、マスターゲインの設定が更新されます。 更新後の設定をさらに変更したい場合は、そのまま続けて別の値を入力します。

シャッタースピードの設定

- **1** SELECTボタンを押してグリーンのランプを点灯させます。
- **2** SHUTTERボタンを押して点灯させます。 LCDの表示が入力待ち表示に変わります。

SHUTTER ? 0 = 0 FF \bullet I = I / I 0 0 4 = 1 / 5 0 0

2 = 1 / 1 2 5

5 = 1 / 1 0 0 0

3 = 1 / 250

6 = 1 / 2 0 0 0

◆:現在の選択値を示します。

0=OFF: 0を入力するとシャッターがOFFになります。(0=ONのときは、0を入力するとシャッターがONになります。)

3 数字キーを使って希望のシャッタースピードを示す番号(1、2、3、4、5、または6) を入力します。

入力が終了すると、選択されたシャッタースピードを示す番号の前に◆表示が移動 し、シャッタースピードの設定が更新されます。

更新後の設定をさらに変更したい場合は、そのまま続けて別の番号を入力します。

NDフィルター ポジションの設定

- **1** SELECTボタンを押してグリーンのランプを点灯させます。
- **2** NDボタンを押して点灯させます。 LCDの表示が入力待ち表示に変わります。 (表示例)

SS: 1000 SET = 2 SCN242 $+ 18 dB ND = 1 CC = A \downarrow 243$ ND FILTER ? 0 = C T R L

- **3** ND/CC CTLランプが消灯している場合は、0を入力して点灯させます。
- 4 数字キーを使って、希望のNDフィルターポジションを示す番号を入力します。

1:素通し **3**:1/8.ND

2:1/4 ND 4:1/16 ND

入力が終了すると、NDフィルターポジションの設定が更新されます。 更新後の設定をさらに変更したい場合は、そのまま続けて別の番号を入力します。

CCフィルターポジションの設定

- 1 SELECTボタンを押してグリーンのランプを点灯させます。
- 2 CCボタンを押して点灯させます。 LCDの表示が入力待ち表示に変わります。

(表示例)

SS: 1000 SET = 2 SCN242 + 1 8 d B N D = 1 C C = A \downarrow 2 4 3 CC FILTER ? 0 = C T R LI = A 2 = B 3 = C 4 = D

- **3** ND/CC CTLランプが消灯している場合は、0を入力して点灯させます。
- 4 数字キーを使って、希望のCCフィルターポジションを示す番号を入力します。


1: A (クロス) **3**: C (4300K)

2:B (3200K) 4:D (6300K)

入力が終了すると、CCフィルターポジションの設定が更新されます。更新後の設定 をさらに変更したい場合は、そのまま続けて別の番号を入力します。

ホワイトバランスの自動調整

1 下図の条件を満たすようにカメラでホワイトパターン(白い紙や壁でもよい)を写します。



- **2** SELECTボタンを押してオレンジのランプを点灯させます。
- **3** AUTO SETUPボタンを押して点灯させます。 LCDの表示が入力待ち表示に変わります。

A U T O S E T U P S E L E C T

I = W H I T E 2 = B L A C K

3 = L E V E L

9 = R E F E R E N C E S T O R E

4 数字キーで「1」を入力します。

ホワイトバランスが自動的に調整されます。調整が終了すると、LCDに終了メッセージが現れます。

AUTO SETUP <WHITE>

約5秒後に、LCDは上記ステップ3の入力待ち表示に戻ります。

ブラックバランスの自動調整

- **1** SELECTボタンを押してオレンジのランプを点灯させます。
- **2** AUTO SETUPボタンを押して点灯させます。 LCDの表示が入力待ち表示に変わります。

A U T O S E T U P S E L E C T

I = W H I T E 2 = B L A C K

3 = L E V E L

9 = R E F E R E N C E S T O R E

3 数字キーで「2」を入力します。 ブラックバランスとブラックセットが自動的に調整されます。調整が終了すると、 LCDに終了メッセージが現れます。

AUTO SETUP < BLACK>

Completed !!

約5秒後に、LCDは上記ステップ2の入力待ち表示に戻ります。

自動レベル調整

下記の手順を実行すると、ブラック、ガンマ、フレア、ブラックセット、ニーポイント、およびニースロープの値が、リファレンスファイルに保存されている値に従って自動的 に調整されます。

- **1** SELECTボタンを押してオレンジのランプを点灯させます。
- **2** AUTO SETUPボタンを押して点灯させます。 LCDの表示が入力待ち表示に変わります。

A U T O S E T U P S E L E C T

| = W H | T E 2 = B L A C K

3 = L E V E L

9 = R E F E R E N C E S T O R E

3 数字キーで「3」を入力します。

ブラック等のレベルが自動的に調整されます。調整が終了すると、LCDに終了メッセージが現れます。

AUTO SETUP < LEVEL>

Completed !!

約5秒後に、LCDは上記ステップ2の入力待ち表示に戻ります。

オートセットアップ操作の中止

オートセットアップ操作を途中で中止したいときは、CANCELボタンを押します。 LCDの4行目に「Operation break」メッセージが表示され、操作は中止されます。

(表示例)

AUTO SETUP < LEVEL>

Gamma BAL : B-ch Operation break

約5秒後に、LCDは上記ステップ2の入力待ち表示に戻ります。

エラーが発生すると

オートセットアップの実行中にエラーが発生すると、LCDにエラーメッセージが表示されて操作は中止されます。エラーメッセージを消去するには、本機のいずれかのボタンを押します。

この操作の手順は、IDコードが未登録か登録済みかで異なります。

IDコードが未登録のとき

- **1** SELECTボタンを押してオレンジのランプを点灯させます。
- **2** AUTO SETUPボタンを押して点灯させます。 LCDの表示が次に示す入力待ち表示に変わります。

A U T O S E T U P S E L E C T

| = W H | T E 2 = B L A C K

3 = L E V E L

9 = R E F E R E N C E S T O R E

3 数字キーで「9」を入力します。 リファレンスファイルの内容更新と保管が実行されます。終了すると、LCDに終了 メッセージが現れます。

REFERENCE STORE

Completed !!

約5秒後に、LCDは上記ステップ2の入力待ち表示に戻ります。

IDコードが登録済みのとき

- **1** SELECTボタンを押してオレンジのランプを点灯させます。
- **2** AUTO SETUPボタンを押して点灯させます。 LCDの表示が入力待ち表示に変わります。

A U T O S E T U P S E L E C T

I = W H I T E 2 = B L A C K

3 = L E V E L

9 = R E F E R E N C E S T O R E

3 数字キーで「9」を入力します。

LCDの表示がIDコード入力待ち表示に変わります。

REFERENCE STORE

ID CODE ?

4 数字キーで登録済みIDコードを入力します。

入力したIDコードがLCDに表示され、リファレンスファイルの内容更新と保管が実行されます。終了すると、LCDに終了メッセージが現れます。

REFERENCE STORE

Completed !!

約5秒後に、LCDは上記ステップ2の入力待ち表示に戻ります。

入力した数値が正しくないとき

IDコードとして入力した数値が間違っているときは、LCDに次のような表示が現れます。

(表示例)

REFERENCE STORE

ID CODE 12 NG!

登録済みIDコードを確認して入力し直してください。

リファレンスファイル保管操作の中止

リファレンスファイル保管操作を途中で中止したいときは、CANCELボタンを押します。

LCDに「Operation break」メッセージが表示され、操作は中止されます。

(表示例)

REFERENCE STORE

Gamma BAL : B-chOperation break

約5秒後に、LCDは上記ステップ2の入力待ち表示に戻ります。

エラーが発生すると

リファレンスファイル保管の実行中にエラーが発生すると、LCDにエラーメッセージが 表示されて操作は中止されます。エラーメッセージを消去するには、本機のいずれかの ボタンを押します。

ガンマ値の設定

- 1 SELECTボタンを押してオレンジのランプを点灯させます。
- **2** GAMMAボタンを押して点灯させます。 LCDの表示が入力待ち表示に変わります。

(表示例)

GAMMA SELECT 0 = 0 N i = 0. 4 2 = 0. 4 5 3 = 0. 5

◆:現在の選択値を示します。

0=ON: 0を入力するとガンマ回路がONになります。(0=OFFのときは、0を入力 するとガンマ回路がOFFになります。)

3 数字キーを使って希望のガンマ値を示す番号(1、2、3)を入力します。 入力が終了すると、選択されたガンマ値を示す番号の前に◆表示が移動し、ガンマ 値の設定が更新されます。

更新後の設定をさらに変更したい場合は、そのまま続けて別の番号を入力します。

本機の操作により、カメラに内蔵されている次の回路のオン/オフ切り換えを行うことができます。

- 高輝度光に対して自動的にニーを働かせるためのオートニー回路
- ●ニー補償回路
- ●輪郭補正を行うディテイル回路
- ●忠実な色再現を行うためのリニアマトリックス回路
- **1** SELECTボタンを押してオレンジのランプを点灯させます。
- **2** SWITCHボタンを押して点灯させます。 LCDに入力待ち表示の第1ページが表示されます。 (第1ページの表示例)

- ◆:現在オンになっている回路を示します。
- 3 数字キーを使って、オン/オフを切り換えたい回路の番号を入力します。
 - 「◆」が付いていない番号を入力すると対象回路がオンになり、「◆」が付いている 番号を入力すると対象回路がオフになります。

1: atKNEE (オートニー回路)5: ----- (未使用)2: KNEE (ニー補償回路)6: ----- (未使用)3: DETAL (ディテイル回路)7: ----- (未使用)

4: MATRIX (リニアマトリックス回路) **8**: next PG (第2ページを表示)*

*「8」を入力すると、入力待ち表示の第2ページに切り換わりますが、第2ページでの操作は、カメラコントロールユニットにオプション基板を取り付けたときのみ可能です。詳しくはカメラコントロールユニットのオペレーション アンド メンテナンスマニュアルをご覧ください。

本機には、特殊ファンクションとして次の機能が用意されています。

- ●ペイントデータをすべてクリアする (ベースのセットアップ状態に戻す)。
- ●カメラ内部で使用するテスト波形をガンマ波形と階段波形の間で切り換える。
- ●IDコードを登録/変更する。(1-16 (J) ページ)
- ●シーンファイルの削除。

ペイントデータのクリア/テスト波形の切り換え

- **1** SELECTボタンを押してオレンジのランプを点灯させます。
- **2** SYSTEMボタンを押して点灯させます。 LCDの表示が入力待ち表示に変わります。 (表示例)

0 = ALL PAINT CLEAR

1 = TEST 1/2 SELECT → 1

2 = ID REGISTRATION

3 = SCENE FILE DELETE

- 3 数字キーを使って、実行したい機能の番号を入力します。
 - **0**: すべてのペイントデータをクリアする。
 - 1: テスト波形を切り換える。

「1」の数字キーを押すたびに、TEST1 (ガンマ波形) とTEST2 (階段波形) が交互に選択されます。

矢印の右側の数字が現在の選択を示します。

→1:TEST1 (ガンマ波形)

→2:TEST2 (階段波形)

シーンファイルの削除

- 1 SELECTボタンを押してオレンジのランプを点灯させます。
- 2 SYSTEMボタンを押して点灯させます。

0 = ALL PAINT CLEAR

1 = TEST 1/2 SELECT → 1

2 = ID REGISTRATION

3 = SCENE FILE DELETE

3 数字キーで「3」を入力します。

SCENE FILE DELETION 0 = ALL 1 = ONE

- 4 すべてのシーンファイルを削除したいときは
 - 数字キーで「0」を入力します。
 LCDに「ALL SCENES DELETING?」が表示され、CANCELボタンとCLEARボタンが点滅します。
 - 2) ファイルを削除するには: CLEARボタンを押します。 削除をやめたいときは: CANCELボタンを押します。 約5秒後に、LCDはステップ2の表示に戻ります。

特定のシーンファイルを削除したいときは

- 1) 数字キーで「1」を入力します。 LCDは、ファイル番号の入力待ち表示になります。
- 削除したいファイル番号を入力します。
 LCDに入力したファイル番号が表示されます。
- 3) CLEARボタンを押します。
 - 入力したファイル番号が存在するとき:

LCDに「SCENE FILE DELETING?」が表示され、CANCELボタンとCLEARボタンが点滅します。

ファイルを削除するには: CLEARボタンを押します。

削除をやめたいときは: CANCELボタンを押します。

- 入力したファイル番号が存在しないとき: LCDに「File not exists!」が表示され、約5秒後にLCDはステップ3の表示に戻り ます。


シーンファイルの削除をやめたいときは

CANCELボタンを押します。

約5秒後に、LCDはステップ2の表示に戻ります。

1-4-2. 手動調整

手動調整部のボタンとコントロールを使用して、カメラの設定項目を手動調整することができます。操作手順は次の通りです。



1 希望の調整項目選択ボタンを押します。

LCDの4行目に選択された項目名が表示され、LED表示器に現在の調整値が表示されます。

(LCDの表示例:ホワイトバランスの手動調整のためにWHITEボタンを押した場合)

(LED表示器の表示例)



(左からR、G、Bに対応。+5%、-10%、+7%を表します。)

2 LED表示器の下の調整つまみを回して調整を行います。

調整項目名、調整項目選択ボタン名、調整範囲、LCDに表示される項目名、LED表示器に表示される調整値(調整可能範囲に対するパーセント)の範囲は次表のとおりです。

調整項目名	調整項目選択	調整可能	LCDの項目表示 LED表示*の範囲		
	送が				
R, G, B	WHITE	±5.5dB	< <white>></white>		
ホワイトバランス			±99% ±99% ±99%		
R, G, B	BLACK	±20IRE	< <black>></black>		
ブラックバランス			±99% ±99% ±99%		
R、G、B フレアバランス	FLARE	±10IRE	< <flare>></flare>		
			±99% ±99% ±99%		
R、G、B ガンマバランス	GAMMA	±0.03	< <gamma>></gamma>		
			±99% ±99% ±99%		
ディテイルレベル	DETAIL	0~+10dB	LEVEL LIMITER CRIS		
ディテイルリミッター クリスプニング			±99% ±99% 0~+99%		
マスターガンマ	KNEE	±0.03 ±15% ±10%	M.GAM M.KNEE M.SLO		
マスターニーポイント マスターニースロープ	KNEE		±99% ±99% ±99%		
R、G、Bバーティカル モジュレーション	V MOD	±15%	< <v mod="">></v>		
			±99% ±99% ±99%		
SC位相、H位相	PHASE	(1-14(J)ページ「位相調整」参照。)		

^{*+}符号と%記号は表示されません。

現在の調整値を基準にし、それに対する変化量を確認しながら調整したいときは、次の 手順に従います。


- 1 希望の調整項目選択ボタンを押します。 LCDの4行目に選択された項目名が表示され、LED表示器に現在の調整値が表示されます。
- **2** OFFSETボタンを押して点灯させます。 各LED表示器が「0」を表示します。
- 3 LED表示器の下の調整つまみを回して調整します。 LED表示器に、OFFSETボタンを押した時点の調整値からの変化量(差分)が表示されます。
 - ●OFFSETボタンをもう一度押して消灯させると、オフセットモードが解除されて、 LED表示器は通常の表示モードに戻ります。 たとえば、オフセットモードにする前の表示が「10」%だった場合、オフセット

モードで「-5」%に調整してから通常のモードに戻すと、LED表示器には「5」%と表示されます。

手動調整値のクリア

次の手順により、任意の項目の手動調整値をクリアして、手動調整前の値(ホワイトバランスとブラックバランスはオートホワイト、オートブラックの値)に戻すことができます。


- 1 CLEARボタンを押して点滅させます。 もう一度押すと消灯し、クリア操作は中止されます。
- 2 希望の調整項目選択ボタンを押して点灯させます。 CLEARボタンが点滅を止めて消灯し、選択された項目の手動調整値がクリアされます。



- **1** IRIS調整レバー (RCP-3730) またはIRIS調整つまみ (RCP-3731) を中央の位置に します。
- **2** AUTO IRISボタンを押して点灯させます。 絞りは入力光量に応じて最適値に自動調整されます。

自動調整の基準値を変えるには

AUTO IRISボタンが点灯し、絞りが自動調整になっているとき、IRIS調整レバーまたは IRIS調整つまみを動かすと、自動調整の基準値を±1Fの範囲で変えることができます。



調整範囲の設定

- AUTO IRISボタンが点灯しているときは、ボタンを押して消灯させます。
- **2** IRIS調整レバー (RCP-3730) またはIRIS調整つまみ (RCP-3731) を中央の位置に します。
- **3** IRIS COARSEつまみで、IRIS調整レバーまたはIRIS調整つまみによる調整範囲の中心値を設定します。
- 4 RCP-3730の場合は、IRIS調整レバーを上下両方向いっぱいに動かし、RCP-3731の場合は、IRIS調整のまみを左右いっぱいに回して、絞りの調整範囲を確認します。

調整範囲の大きさを変更したいときは、ドライバーでSENS調整ねじを回して調整します (右へ回すと調整範囲が狭くなります)。

調整

IRIS調整レバーまたはIRIS調整つまみを動かして、最適な映像が得られるように絞りを調整します。

マスターブラック調整リング (RCP-3730) またはMASTER BLACK調整つまみ (RCP-3731) を回して調整します。

マスターブラック調整リングを回すと、マスターブラックインジケーターも一緒に回転し、おおよその調整量を示します。調整値はMASTER BLACK表示部にパーセント (-99%~+99%の範囲) で表示されます。

絶対値モードと相対値モードについて

RCP-3730のIRIS調整レバーとマスターブラック調整リング、RCP-3731のIRIS調整つまみとMASTER BLACK調整つまみの働きは、RELATIVEボタン消灯時は絶対値モード、点灯時は相対値モードになります。

絶対値モード:レバーやつまみの位置が調整項目の値と絶対的に対応しており、中央位置がそのまま調整範囲の中央値に対応します。

相対値モード:レバーやつまみの位置と調整値との絶対的な対応関係がなくなります。 すなわち、中央位置は必ずしも調整範囲の中央値に対応せず、絶対値 モードから相対値モードに切り換わるときの位置が、その後の相対値調 整の基準位置になります。

ご注意

AUTO IRISボタンを押して消灯させ、絞りを自動調整から手動調整に切り換えるときに、RELATIVEボタンが消灯していると(絶対値モード)、絞りは瞬間的に、そのときのIRIS調整レバー(RCP-3730)、IRIS調整つまみ(RCP-3731)の位置に対応する値に変わります。したがって、切り換え時のレバー(つまみ)の位置によっては、映像の明るさが大きく変化することがあります。

AUTO IRISボタン点灯中にRELATIVEボタンを押して点灯させておくと(相対値モード)、手動調整に切り換えても直前の自動調整値が保持されるため、上記の現象を避けることができます。

1-4-4. ファイル操作


ファイル操作ボタンと数字キーを使用して、セットアップファイルとシーンファイルの作成・保管、および呼び出しを行うことができます。(リファレンスファイルの保管については1-27 (J) ページをご覧ください。)

ご注意

- ●ファンクション選択ボタンが点灯していると、ファイル操作は行えません。点灯しているボタンを押して消灯させてください。
- ●ファイル操作エラーが生じると、LCDは4行目にエラーメッセージを表示し、約5秒後に通常表示 (1-19 (J) ページ) に戻ります。

セットアップファイル操作

A. セットアップファイルの保管



現在の調整値をセットアップファイルに保存する手順は、IDコードが未登録か登録済みかで異なります。

IDコードが未登録のとき

1 SETUPボタンを押して点灯させます。 LCDの表示がファイル番号入力待ち表示に変わります。 (表示例)

SS: | 0 0 0 SET=2 SCN242 + | 8 dB ND=1 CC=A $\downarrow 243$ Setup No. << WH.ITE >>

2 数字キーで希望のファイル番号 (1~8)*を入力します。 入力したファイル番号がLCDに表示されます。

(表示例:ファイル番号1を入力した場合)

SS: I 0 0 0 SET = 2 SCN 2 4 2 + I 8 d B N D = I C C = A ↓ 2 4 3 ► Setup No. I << WHITE >>

ファイル番号を間違えて入力した場合は、その場で再入力できます。

- *既存のファイルの番号を入力して次のステップ3を実行すると、そのファイルは上書きされますのでご注意ください。(1-41 (J) ページ「既存のファイルを指定したとき」参照。)
- **3** STOREボタンを押します。

現在の調整値が、指定した番号のセットアップファイルに保存され、LCDの1行目のセットアップファイル番号の表示が更新されます。

(表示例:ファイル番号1を指定した場合)

SS: 10000 SET=1 SCN242 +18dB ND=1 CC=A ↓243 ►Setup No. 1 Store << WHITE >>

IDコードが登録済みのとき

1 SETUPボタンを押して点灯させます。 LCDの表示がファイル番号入力待ち表示に変わります。 (表示例)

SS: 1000 SET = 2 SCN242 + 18dB ND = 1 CC = A ↓ 243 ▶ Setup No. << WH!TE >>

2 数字キーで希望のファイル番号 (1~8)*を入力します。 入力したファイル番号がLCDに表示されます。 (表示例:ファイル番号1を入力した場合)

SS: 1000 0 SET = 2 SCN242 + 18dB ND = 1 CC = A ↓ 243 ▶ Setup No. 1 << WHITE >>

ファイル番号を間違えて入力した場合は、その場で再入力できます。

- *既存のファイルの番号を入力してステップ3、4を実行すると、そのファイルは上書きされますのでご注意ください。(1-41(J)ページ「既存のファイルを指定したとき」参照。)
- 3 STOREボタンを押します。 LCDがIDコード入力待ち表示に変わります。 (表示例)

SS: 10000 SET=2 SCN242 + 18dB ND=1 CC=A \downarrow 243 > Setup No. 1 Store 1D code ?

4 数字キーで、2桁の登録済みIDコードを入力します。

入力したIDコードがLCDに表示されます。IDコードが正しければ、現在の調整値が、指定した番号のセットアップファイルに保存され、LCDの1行目のセットアップファイル番号の表示が更新されます。

LCDは約5秒後に通常表示に戻ります。

入力したIDコードが正しくないとき

IDコードとして入力した数値が間違っているときは、LCDに次のような表示が現れます。

(表示例:IDコードとして入力した12が間違いの場合)

SS: 10000 SET=2 SCN242 +18dB ND=1 CC=A ↓243 ►Setup No. 1 Store 1D code 12 NG!

登録済みIDコードを確認して入力し直してください。


既存のファイルを指定したとき

既存セットアップファイルの番号を指定して保管操作を実行すると、そのファイルは上書きされて、保存されていた調整値が新しい調整値に書き換えられます。既存のファイルを誤って上書きした場合は、すぐに(次のファイル操作を行う前に)CANCELボタンを押します。LCDに「Command CANCELLED!」と表示され、ファイルは上書き前の状態に戻ります。

(表示例:既存のセットアップファイル1に上書きした後で、上書きを取り消した場合)

SS: 10000 SET= 1 SCN242 + 18dB ND= 1 CC= A ↓ 243 ► Setup No. 1 Store Command CANCELLED!

B. セットアップファイルの呼び出し



1 SETUPボタンを押して点灯させます。 LCDの表示がファイル番号入力待ち表示に変わります。 (表示例)

2 数字キーで希望のファイル番号(1~8)を入力します。 入力したファイル番号がLCDに表示されます。 (表示例:ファイル番号3を入力した場合)

```
SS: 1000 SET = 2 SCN242
+ 18dB ND = 1 CC = A ↓ 243
► Setup No. 3
<< WHITE >>
```

ファイル番号を間違えて入力した場合は、その場で再入力できます。

3 RECALLボタンを押します。

指定したセットアップファイルが呼び出され、LCDの1行目のセットアップファイル番号の表示が更新されます。

(表示例:セットアップファイル3を呼び出した場合)

SS: 1000 SET = 3 SCN242 + 18dB ND = 1 CC = A \ 243 Setup No. 3 Recall << WHITE >>

約5秒後に、LCDは通常表示に戻ります。

指定したセットアップファイルが存在しないとき

LCDに「File not found!」と表示され、セットアップファイルの呼び出しが中止されます。

(表示例:ファイル番号3を指定したが、そのファイル番号のセットアップファイルが存在しない場合)

SS: 1000 SET=2 SCN242 + 18dB ND=1 CC=A ↓ 243 ► Setup No. 3 Recall File not found!

約5秒後に、LCDは通常表示に戻ります。

希望のファイルとは異なるファイルを呼び出したとき

すぐに(次のファイル操作を行う前に) CANCELボタンを押します。


LCDに「Command CANCELLED!」と表示され、セットアップファイル呼び出し前の設定に戻ります。

(表示例:セットアップファイル3を呼び出した後で、取り消した場合)

SS: 10000 SET=2 SCN242 + 18dB ND=1 CC=A \ \ 243 Setup No. 3 Recall Command CANCELLED!

A. シーンファイルの保管

撮影場面に合わせて調整した設定項目の値をシーンファイルに保存するには、次の手順 を実行します。



1 SCENEボタンを押して点灯させます。 LCDの表示がファイル番号入力待ち表示に変わります。 (表示例)

2 数字キーで希望のファイル番号 (001~999) を入力します。 入力したファイル番号がLCDに表示されます。

(表示例:ファイル番号112を入力した場合)

ファイル番号を間違えて入力したときは、その場で再入力できます。

ご注意

1桁または2桁のファイル番号を入力するときは、頭に「00」または「0」を付ける必要はありません。ただし、再入力の場合は、頭に「00」または「0」を付けて3桁にして入力してください。

3 STOREボタンを押します。

指定したシーンファイルが存在しないとき

指定したシーンファイルが作成され、現在の調整値を保管します。同時にLCDの1行目のシーンファイル番号と2行目のネクストシーンファイル番号(↓で表示)の表示が更新されます。

(表示例:ファイル番号に112を指定してシーンファイルを保管し、ネクストシーンファイル番号が113の場合)

```
SS: 1000 SET=1 SCNII2
+ 18dB ND=1 CC=A ↓ 113
▶ Scene No. 112 Store
<< WHITE >>
```

約5秒後に、LCDは通常表示に戻ります。

指定したシーンファイルがすでに存在するとき

LCDに「File already exists!」と表示され、STOREボタンとCANCELボタンが点滅してファイル番号の再入力を促します。

(表示例:ファイル番号112を指定してシーンファイルを保管しようとしたが、現在 使用中のセットアップファイルのもとに、同じ番号のシーンファイルがすでに存在 する場合)

```
SS: 1000 SET = 2 SCN242
+18dB ND = 1 CC = A \ 243
Scene No. 112 Store
File already exists!
```

上書きしたいときはSTOREボタンを、ファイルの保管を中止したいときはCANCELボタンを押します。

もし誤って既存のシーンファイルに上書きした場合は、すぐに(次のファイル操作を行う前に)CANCELボタンを押します。

LCDに「Command CANCELLED!」と表示され、上書きは取り消されます。 (表示例:既存のシーンファイル112に上書きした後で、上書きを取り消した場合)

```
SS: 10000 SET = 2 SCN | 12
+ 18 dB ND = 1 CC = A \downarrow | 13

Scene No. | 12 Store

Command CANCELLED!
```


すでにシーンファイルが8個存在するとき

1個のセットアップファイルにもとづいて作成できるシーンファイルは8個までです。現在使用しているセットアップファイルのもとにすでに8個のシーンファイルが存在する場合は、それらのシーンファイルの番号とは異なる番号をステップ2で入力したまま、ステップ3でSTOREボタンを押すと、LCDに「Scene file full!」と表示され、ファイルの保管は中止されます。

(表示例:ファイル番号112を指定してシーンファイルを保管しようとしたが、現在 使用中のセットアップファイルのもとに、シーンファイルがすでに8個存在する場合)

```
SS: 10000 SET=2 SCN242
+ 18dB ND=1 CC=A \downarrow 243
\blacktriangleright Scene No. 112 Store
Scene file full!
```

B. シーンファイルの呼び出し



1 SCENEボタンを押して点灯させます。 LCDの表示がファイル番号入力待ち表示に変わります。 (表示例)

2 数字キーで希望のファイル番号 (001~999) を入力します。 入力したファイル番号がLCDに表示されます。 (表示例:ファイル番号112を入力した場合)

ファイル番号を間違えて入力したときは、その場で再入力できます。

ご注意

1桁または2桁のファイル番号を入力するときは、頭に「00」または「0」を付ける必要はありません。ただし、再入力の場合は、頭に「00」または「0」を付けて3桁にして入力してください。

3 RECALLボタンを押します。

指定したシーンファイルが呼び出され、LCDの1行目のシーンファイル番号と2行目のネクストシーンファイル番号(↓で表示)の表示が更新されます。

(表示例:ファイル番号に112を指定してシーンファイルを呼び出し、ネクストシーンファイル番号が113の場合)

```
SS: | 0 0 0 SET = 2 SCN | | 2
+ | 8 dB ND = | CC = A ↓ | | 3
▶ Scene No. | | 2 Recall
<< WHITE >>
```

約5秒後に、LCDは通常表示に戻ります。

指定したシーンファイルが存在しないとき

LCDに「File not found!」と表示され、シーンファイルの呼び出しが中止されます。

(表示例:ファイル番号112を指定したが、そのファイル番号のシーンファイルが存在しない場合)

```
SS: 1000 SET = 2 SCN242
+ 18dB ND = 1 CC = A \downarrow 243
> Scene No. 112 Recall
File not found!
```

約5秒後に、LCDは通常表示に戻ります。

希望のファイルとは異なるファイルを呼び出したとき

すぐに(次のファイル操作を行う前に)CANCELボタンを押します。

LCDに「Command CANCELLED」と表示され、シーンファイル呼び出し前の設定に戻ります。

(表示例:シーンファイル113を呼び出した後で、取り消した場合)

```
SS: 1000 SET = 3 SCN242
+ 18dB ND = 1 CC = A ↓ 243
▶ Scene No. 113 Recall
Command CANCELLED!
```

ネクストシーンファイルを呼び出したいとき

ステップ2でNEXTボタンを押すと、LCDの2行目の「↓」の右側に表示されているネクストシーンファイルが直ちに呼び出されます。したがってこの場合は、ステップ3へ進む必要はありません。

ご注意

ネクストシーンファイルが存在しない(「↓」の右側にファイル番号が表示されていない) ときにNEXTボタンを押すと、LCDに「File not found!」と表示され、呼び出しは中止さ れます。

(表示例)

SS: I 0 0 0 SET = 2 SCN 2 4 2+ $I 8 d B ND = I CC = A \downarrow ---$ > Scene No. NextFile not found!

1-4-5. LCDメッセージ一覧

本機のLCDに表示される主なメッセージは次の通りです。

ファイル操作関係

メッセージ	意味	
File not found!	指定されたファイルが見つからない。	
File already exists!	同じ番号のファイルがすでにある。	
Command CANCELLED!	前のコマンドを無効にした。	
Scene file full!	すでに8個のシーンファイルが作成されている。	
Key input error!	キーの入力が無効。	
Setup No. * Store	セットアップファイル No. * を保管した。	
Setup No. * Recall	セットアップファイル No. * を呼び出した。	
Scene No. *** Store	シーンファイル No. *** を保管した。	
Scene No. *** Recall	シーンファイル No. *** を呼び出した。	

オートセットアップ/リファレンスファイル保管関係

メッセージ	意味		
Completed !!	コマンドの実行が完了した。		
ID CODE ** NG!	入力されたIDコードが間違っている。		
Operation break	操作が途中で中止された。		
NEW ID CODE ** Store	IDコード**を登録した。		
ID code erased	IDコードを消去した。		
Overflow	内部的に求められた調整値がオートセットアップ可 能な調整値の範囲を越えた。		
Low level	ビデオレベルが低すぎる。		
Time limit	所定の時間内にオートセットアップが完了しなかっ た。		
Not closed	絞りがクローズしない。		
Not opened	絞りがオープンしない。		

他機の自己診断関係

メッセージ	意味		
RAM lost	カメラヘッドのRAMに異常がある。		
CHU ** NG	カメラヘッドの**基板に異常がある。		
CCU ** NG	カメラコントロールユニットの**基板に異常があ る		

1-5. 仕様

入出力コネクター

CCUコネクター (16ピン)

PREVIEWコネクター (6ピン)

電源

DC 30V

消費電力

5W

最大ケーブル長

200m (CCA-2ケーブルまたは同等品使用の場合)

重量

RCP-3730: 2.5kg

RCP-3731: 2.3kg

外形寸法(幅/高さ/奥行き)

RCP-3730:102×376×127mm

RCP-3731:102×376×84mm

(突起部を含む)

付属品

16ピンコネクター (2)

6ピンコネクター (1)

ナンバープレート (1式)

オペレーション アンド メンテナンスマニュアル (1)

別売りアクセサリー

カメラ接続ケーブル (CCA-2-30)

本機の仕様および外観は、改良のため予告なく変更することがありますが、ご了承ください。

Section 1. OPERATION

1-1. Overview

The RCP-3730/3731 remote control panel is used to remote-control the BVP-370/370P/270/270P 3-chip CCD color video camera via the CCU-370 camera control unit. By using an optional connecting cable, the distance between the remote control panel and the camera control unit can be extended up to 200 m.

The RCP-3730 and RCP-3731 have the same functions. They only differ in the construction of their iris and master black adjustment block. Whereas the RCP-3730 has a joystick and a ring for adjusting the iris and master black, the RCP-3731 has knobs for the same functions.

1-1-1. Features

The remote control panel has the following features:

Control parts arranged for easy and error-free operation

The controls such as buttons and knobs are arranged according to function with consideration given to how frequently they will be used. Buttons light or flash to indicate the state of operation. In addition, the buttons which, if pressed by mistake, might seriously affect the camera operation or setup are provided with a guard frame. This and other features ensure easy and error-free execution of various functions of the remote control panel.

Liquid crystal display showing useful information

The LCD (liquid crystal display) shows information on the item being adjusted and files being used, prompting messages, system messages, and so on. By looking at the LCD, you can quickly grasp the current condition of the camera system.

Automatic setup function

The auto setup function performed using microcomputers can automatically set up most control items at a time, and white level and black level individually.

Reference file function

The reference values for automatic adjustment of most control items have been factory set in the camera head. If desired, you can set and store new reference values in the reference file to be retained in the camera head.

Setup file function

Up to eight sets of setup data adjusted for different setup conditions can be stored in setup files to be retained in the camera head. You can recall any of them to set up the camera automatically according to the data stored in the file.

Scene file function

Painting data prepared for a particular scene can be stored in a scene file to be retained in the camera head. You can recall it to set up the camera automatically when shooting the identical scene. You can create up to eight scene files based on each setup file (that is, a total of up to 64 scene files based on setup files 1 to 8).

File security function

You can set an ID code to be used for the storing of the reference file or setup files. With an ID code set, no one can store the reference file or setup files without keying in the ID code.

Electronic shutter control

The electronic shutter of the CCD camera can be switched on and off from the remote control panel. You can also change the shutter speed in a range of six speeds.

Signal transmission via digital line

Between the remote control panel and the camera control unit, signals are digitally transmitted via a single connection cable (CCA-2), ensuring reliable signal transmission.

Concurrently operable with a master setup unit

The remote control panel can control the camera concurrently with the master setup unit. Concurrent control is possible in two modes: parallel mode and split mode. All functions of the remote control panel are available in parallel mode, whereas you can use only the iris and master black adjustment block in split mode.

Betacam camera control

When connected to the CCU-350/350P/355/355P camera control unit, the remote control panel can be used to control a Betacam-series camera (such as the BVP-7/7P/50/50P/70/70P/7000HS/7000HSP) attached with a camera adaptor.

Four units mountable on 19-inch rack

Up to four units of the remote control panel can be mounted on a 19-inch EIA standard rack (7 rack units high).

This remote control panel is designed exclusively for use with CCD color video cameras. You cannot use it to control video cameras with a tube type pickup device.

File System

The BVP-370 series video cameras can store the following three types of files containing the reference or adjustment data in the camera head:

- 1. Reference file
- 2. Setup files
- 3. Scene files

File operations such as file storage and recalling are performed from the MSU-350 master setup unit or the RCP-3720/3721/3730/3731 remote control panel. The types and numbers of files that can be used vary with the type of control panel to be used. The items of data that can be stored in the files also differ depending on the type of camera. For details, refer to the operation and maintenance manual for the camera to be used.

1. Reference file

The reference file stores the reference values for auto setup adjustment. When auto setup adjustment is carried out, the control items are automatically adjusted to the reference values. This file is the basis of the entire file system. The initial reference values for each camera are factory set. You can change them as desired and store them in the reference file.

The contents of the reference file remain unchanged until new reference values are set and stored in it.

2. Setup files

Setup files store different sets of manually adjusted setup data. For example, you may store setup data adjusted for use under different indoor or outdoor shooting conditions in numbered setup files. You can recall them when required to carry out shooting under similar conditions. When a setup file is recalled, the camera is set up automatically according to the data contained in the file so that you can start shooting immediately. The contents of setup files remain unchanged until new data is stored in them. Up to eight setup files can be created.

3. Scene files


Scene files store painting data for different scenes. For example, data prepared in rehearsal for a particular scene may be stored in a scene file. When shooting the scene, you can recall the scene file to automatically reproduce the same camera settings as

The contents of scene files remain unchanged until new data is stored in them. Up to eight scene files can be created based on each setup file (that is, a total of 64 scene files based on setup files 1 to 8).

Data that can be stored in files

item	Reference file	Setup file	Scene file	Value (%) range (see page 1-33(E))
Analog data				And the second s
R, G, B white balance		5 8 5 2 9	Yes	
R, G, B vertical modulation	No	No	No	
R, G, B flare balance	Yes			-99 to +99
Detail level			1	
Detail limiter	No			
Crisping				0 to +99
R, G, B black balance	Yes	Yes	Yes	
R, G, B gamma balance	(G only)		res	
Master gamma				– 99 to +99
Master knee point	No			- 99 10 + 99
Master slope	INO			
Master black		No		
Switch data				
MASTER GAIN			Yes	
TEST1 ON			No	
TEST2 ON		No	INO	
SHUTTER SPEED	No	NO		
FILTER DATA		·		
DETAIL ON				
MATRIX ON			Yes	
AUTO KNEE ON		Yes		
GAMMA SELECT				
GAMMA ON/OFF		No		

1-2. Location and Function of Parts and Controls



PANEL ACTIVE button-

When this button is lit, the remote control panel can control the camera system (see page 1-12(E)).

PARA (parallel mode) button-

Lights or flashes when the remote control panel is in a mode to control the camera system concurrently with the master setup unit (see page 1-12(E)).

CAM PW (camera power) button -

When turned on, this button lights and causes the camera head to be powered.

TEST button-

When turned on, this button lights and causes a gamma or staircase signal to be output (see page 1-30(E)).

BARS (color bar) button

When turned on, this button lights and causes a color bar signal to be output.


CLOSE (iris close) button -

When turned on, this button lights and causes the iris to be closed.

LOCK button -

When turned on, this button lights and makes all buttons and knobs inoperable, excepting those in the iris and master black adjustment block, the CALL button and this button itself.

RCP-3730



Tally block

Camera number indicator

Attach the number plate (supplied) corresponding to the number of the camera connected.

Green tally lamp

Lights when a green tally signal is input to the camera.

-CALL button/red tally lamp

When turned on, this button lights and causes a call signal to be transmitted to the camera head. It also lights when a red tally signal is input to the camera.


Function select switch block (1-(see page 1-19(E))

SELECT button, ▶ (green lamp), and ▶ (orange lamp)

Press this button to light the green lamp or orange lamp alternately. The four buttons in the function select switch block ② work as the MASTER GAIN/SHUTTER (shutter speed)/ND (ND filter)/CC (color temperature conversion filter) buttons with the green lamp lit or as the AUTO SETUP/ GAMMA (gamma select)/SWITCH (switch control)/SYSTEM (system command) buttons with the orange lamp lit.

Note

The SELECT button does not work if there is any button lit in the function select switch block ②. Turn it off before pressing the SELECT button.



Function select switch block ② (see page 1-19(E))

MASTER/SHUTTER/ND/CC buttons (Available when the green lamp is lit.) When any of these buttons is turned on, it lights and makes it possible to set the corresponding item among the master gain, shutter speed, ND filter and CC filter using the LCD and the numeric keys.

AUTO SETUP/GAMMA/SWITCH/ SYSTEM buttons (Available when the orange lamp is lit.)

When any of these buttons is turned on, it lights and makes it possible to carry out auto setup operation, to select a gamma value, to switch on and off control circuits in the camera, or to execute system commands, using the LCD and the numeric keys.

ND/CC CTL (ND/CC filter control) lamp

When "0" is entered while the ND or CC button is lit, this lamp lights, making it possible to select a desired ND or CC filter position. (This lamp, when lit, can be turned off only from the camera side.)

Note

Before carrying out a file operation using the buttons in the file operation block, turn off whatever button lit in the function select switch block ②.

LCD adjustment block-

CONTRAST adjustment screw Adjusts the LCD contrast.

BRIGHT (brightness) adjustment

Adjusts the LCD brightness.

Number input block

Used to enter numbers or data values, for example, during setup operation carried out using the function select buttons or during file operation performed using the file operation buttons.



File operation block (see page 1-37(E))

Used to perform the following functions:

SETUP (setup file) button

Setup file operation (storing/recalling)

SCENE (scene file) button

Scene file operation (storing/recalling)

STORE button

Storing the reference file, a setup file or a scene file, or setting an ID code.

CANCEL button


Canceling auto setup, ID code setting, or file operation.

NEXT (next scene file) button

Recalling the next scene file indicated following "\dagger" on the LCD.

RECALL button

Recalling a setup file or a scene file



Displays camera settings, information necessary to carry out operation using the function select buttons, various messages, and so on.

Manual adjustment block (see page 1-31(E))

Item selector buttons

When turned on, these buttons light and the corresponding item becomes manually adjustable.


WHITE: R/G/B white balance BLACK: R/G/B black balance FLARE: R/G/B flare balance GAMMA: R/G/B gamma balance DETAIL: Detail level/detail limiter/

crisping

KNEE: Master gamma/master knee point/master knee slope

V MOD: R/G/B vertical modulation

PHASE: SC and H phases



CLEAR button

When turned on, this button lights and clears the manual adjustment done on the selected item.

OFFSET button


When turned on, this button lights, resetting the LED displays to 0 and making them subsequently display the values of the selected item relative to the 0-point.

LED displays


These displays show the current adjustment values (in relative mode, if the OFFSET button is lit) of the selected item.

Control knobs

Used to manually adjust the selected







Roc

See the description of the RCP-3730.

PREVIEW button-

When turned on, this button lights and causes a PREVIEW signal to be output from the PREVIEW connector for monitoring the picture.


MASTER BLACK control knob — Used to manually adjust the master black.

-IRIS control knob

Used to manually adjust the iris or to adjust the reference value for automatic iris adjustment.

HEMOTE CONTROL PANEL

Connector panel




PREVIEW connector (6-pin)
Used to output the PREVIEW signal to equipment such as a video switcher and also to receive the power supply for lighting the PREVIEW button (RCP-3731) from the equipment.

- CCU (camera control unit) connector (16-pin)
Connect to the RCP connector of the camera control unit.

1-3. Start-up and Initial Adjustment

1-3-1. Start-up

This remote control panel receives the power supply from the camera control unit connected to its CCU connector.



To make it possible to control your camera system from this remote control panel, turn on the PANEL ACTIVE button.

The buttons and controls that can be used vary with the states of the PANEL ACTIVE button and PARA button as summarized in the table below.

Button name ar	nd state	Buttons and controls usable
PANEL ACTIVE	PARA*1	Duttons and controls usable
	Lit	All buttons and controls*2
Lit	Flashing	Iris and master black adjustment block only
	Unlit	All buttons and controls except PARA button*2
Unlit*3	Lit/ Flashing/ Unlit	PANEL ACTIVE, LOCK, RELATIVE, and function select buttons*4

^{*1} The PARA button lights (parallel mode), flashes (split mode) or goes off according to the setting for concurrent control made on the master setup unit. On the remote control panel, you can only turn it off by pressing while it is lit.


If the LOCK button is lit, you can use no buttons or controls other than those in the iris and master black adjustment block, the CALL button and the LOCK button.

*4 The numeric keys cannot be used.

^{*3} While the PANEL ACTIVE button is unlit, the remote control panel cannot control the camera system, but you can check various settings using the buttons and controls listed as usable in the above table.

1-3-2. Initial Adjustment

Phase adjustment



Connect a waveform monitor and a vector scope to the location selected for phase adjustment and adjust the H and SC phases using the following procedure:

- 1 Turn on the PANEL ACTIVE button.
- 2 Turn on the CAM PW button.

3 Turn on the PHASE button.

The indication "SC≪ PHASE >>H" will appear in the bottom line of the LCD. (Display example)

$$SS: 1000 O SET = 2 SCN ---$$

+ 18 d B N D = 1 C C = A \ \ \ \ ---

Note

The information given in the first and second lines of the display are determined by the current settings.

At the same time, the SC phase will be indicated in degrees (-180° to $+180^{\circ}$) on the left-hand one of the three LED displays, whereas the H phase will be displayed in percent (-99% to +99%) with respect to the adjustable range on the right- hand LED display.

4 Observing the displays on the waveform monitor and vector scope, adjust the H and SC phases to the reference signals by turning the control knobs below the respective LED displays.

1-3-3. ID Code Setting


You can set an ID code (01 to 99) to prevent unauthorized operators from carrying out reference file or setup file storing operation.

The ID code can be set in the following two ways:

- Using the DIP switch S2
- Using the SYSTEM button


If two different ID codes are set, the one set on the DIP switch S2 takes priority. (The DIP switch S2 is factory set to "00".)

Setting ID code using the DIP switch S2



ID code digit	Switch No. (*)	Setting	Decimal value	ID code
	1 (2° = 1)	OFF		- 36
Units	$2(2^1 = 2)$	ON		
	3 (22 = 4)	ON	2 + 4 = 6	
	$4(2^3 = 8)$	OFF		
	$5(2^0=1)$	ON		
Tens	6 (2 [†] = 2)	ON	4 . 6 . 5	
16116	$7(2^2=4)$	OFF	1+2=3	
	8 (23 = 8)	OFF		

^{*} Decimal value represented by each switch



To set an ID code using the SYSTEM button, proceed as follows:

- 1 Light the orange lamp by pressing the SELECT button. (If the orange lamp is already lit, skip this step.)
- 2 Turn on the SYSTEM button.

 The display on the LCD will change into the one for function selection.

 (Display example)

0 = ALL PAINT CLEAR 1 = TEST 1 / 2 SELECT → 1 2 = ID REGISTRATION 3 = SCENE FILE DELETE

3 Key in "2".

The display on the LCD will change into the one for ID code setting.

(Display for ID code setting)

ID REGISTRATION
NEW ID CODE ?

4 Key in a 2-digit ID code other than "00". The ID code entered will appear on the LCD. (Display example)

ID REGISTRATION
NEW ID CODE 99

Press the STORE button.
The ID code will be stored in memory and the LCD will show a "Store" indication.
(Display example)

ID REGISTRATION

NEW ID CODE 99 Store

After 5 seconds or so, the LCD will restore the display shown in step 2.

Note

• If you enter "00" as the ID code or press the STORE button without entering any ID code, the ID code that has been stored will be erased and a message "ID code erased" will appear in the bottom line of the LCD as shown below.

ID REGISTRATION

NEW ID CODE ? Store

ID code erased

After 5 seconds or so, the LCD will restore the display shown in step 2.


- To make the ID code set using the SYSTEM button effective, set the DIP switch S2 to "00" (factory setting).
- To stop setting the ID code before pressing the STORE button, press the CANCEL button. The LCD will restore the display shown in step 2.

1-4. Operation

LCD display

Ordinary display

The LCD ordinarily shows camera settings in the first and second lines, and the item currently selected for adjustment in the fourth line.



Changes in display caused by other equipment


While the display appearing on the LCD changes during operation of the remote control panel, it is also affected by the operation of or error detection in other equipment, for example, as follows:

- When auto setup or reference file storing is started on other equipment, for example, the master setup unit in the same system, the LCD of this remote control panel interrupts the current display and shows the progress of the operation on the external equipment. When the operation is completed, a message "Completed!!" appears on the LCD for about 5 seconds. The LCD then restores the interrupted display.
- If an error is detected by self-diagnosis carried out by the camera or the camera control unit, it will be displayed in the third line of the LCD (unless a function select button is lit) and, at the same time, the CANCEL button will flash.

1-4-1. Function Select Switch Operation

The operations that can be performed using the function select buttons are outlined in the table below.

Button marking	Operation performable		
(upper/lower)	When the green lamp is lit.	When the orange lamp is lit.	
MASTER GAIN/ AUTO SETUP	Setting the master gain. (see page 1-21(E).)	Auto setup (see page 1-23(E)) and reference file storing (see page 1-26(E)).	
SHUTTER/ GAMMA	Setting the shutter speed. (See page 1-21(E).)	Setting the gamma. (See page 1-28(E).)	
ND/SWITCH	Selecting the ND filter position. (See page 1-22(E).)	Switching on/off internal circuits of the camera. (See page 1-29(E).)	
CC/SYSTEM	Selecting the CC filter position. (See page 1-22(E).)	Executing special functions. (See page 1-30(E).)	



1 Light the green or orange lamp by pressing the SELECT button. (If the lamp to be lit is already on, skip this step.)

Note

The SELECT button does not work if there is any button lit in the function select switch block ②. Turn it off before pressing the SELECT button.

- **2** Turn on the function select button corresponding to the function to be performed. The ordinary display appearing on the LCD will change into one to wait for an input (for display examples, see the subsequent explanation of the respective operating procedures).
 - If you press the button again, it will turn off and the LCD will restore an ordinary display.
- 3 Referring to the display on the LCD, key in an appropriate number.

Note

- While any function select button is lit, you cannot operate on any items other than those indicated by the green or orange arrowhead lamp. Turn it off before starting a different operation in a different block.
- To discontinue operation halfway, press the CANCEL button.

- 1 Light the green lamp by pressing the SELECT button.
- 2 Turn on the MASTER GAIN button.

 The display on the LCD will change into the one for master gain selection.

(Display example)

- 3 Key in the number corresponding to the desired master gain level.
 - 0: 0 dB
 - **3:** +3
 - **6:** +6
 - **9:** +9
 - 18: +18

When a number listed above is entered, the master gain setting is updated. If desired, you can enter another number to change the setting again.

Setting the shutter speed

- 1 Light the green lamp by pressing the SELECT button.
- Turn on the SHUTTER button.
 The display on the LCD will change into the one for shutter speed selection.

(Display example)

- •: Indicates the current shutter speed setting.
- 0=OFF: Indicates that entering "0" will turn off the shutter. (Entering "0" with "0=ON" displayed will turn on the shutter.)
- 3 Enter the number (1, 2, 3, 4, 5, or 6) corresponding to the desired shutter speed. When a number listed above is entered, the "♦" on the display moves to that number to indicate the updated shutter speed setting. If desired, you can enter another number to change the setting again.

- 1 Light the green lamp by pressing the SELECT button.
- 2 Turn on the ND button.

 The display on the LCD will change into the one for selecting an ND filter position.

(Display example)

- 3 If the ND/CC CTL lamp is off, enter "0" to turn it on.
- 4 Enter the number corresponding to the desired ND filter position.
 - 1: Clear
 - 2: 1/4 ND
 - 3: 1/8 ND
 - 4: 1/16 ND

When a number listed above is entered, the setting of the ND filter position is updated.

If desired, you can enter another number to change the setting again.

Setting the CC filter position

- 1 Light the green lamp by pressing the SELECT button.
- 2 Turn on the CC button.
 The display on the LCD will change into the one for selecting a CC filter position.

(Display example)


- 3 If the ND/CC CTL lamp is off, enter "0" to turn it on.
- 4 Key in the number corresponding to the desired CC filter position.
 - 1: A (Cross)
 - 2: B (3200K)
 - 3: C (4300K)
 - 4: D (6300K)

When a number listed above is entered, the setting of the CC filter position is updated.

If desired, you can enter another number to change the setting again.

Automatic adjustment of white balance

1 Shoot a white pattern (a substitute such as a sheet of white paper, a white wall, or the like may be used) in such a way that the conditions described below are met.



- 2 Light the orange lamp by pressing the SELECT button.
- 3 Turn on the AUTO SETUP button. The display shown below will appear on the LCD.

4 Key in "1".

The white balance will be adjusted automatically. Upon completion of the automatic white balance adjustment, a completion message will appear on the LCD. (Display example)

```
AUTO SETUP < WHITE>
```

After 5 seconds or so, the LCD will restore the display shown in step 3.

Automatic adjustment of black balance

- 1 Light the orange lamp by pressing the SELECT button.
- 2 Turn on the AUTO SETUP button.
 The display shown below will appear on the LCD.

AUTO SETUP SELECT

I = WHITE 2 = BLACK

3 = LEVEL

9 = REFERENCE STORE

3 Key in "2".

The black balance and black set will be adjusted automatically. Upon completion of the automatic adjustment, a completion message will appear on the LCD. (Display example)

AUTO SETUP <BLACK>

After 5 seconds or so, the LCD will restore the display shown in step 2.

Automatic level adjustment

When the following procedure is performed, the values of black, gamma, flare, blackset, knee point and knee slope are automatically adjusted to the reference values stored in the reference file.

- 1 Light the orange lamp by pressing the SELECT button.
- 2 Turn on the AUTO SETUP button. The display shown below will appear on the LCD.

A U T O S E T U P S E L E C T

| = W H | T E 2 = B L A C K

3 = L E V E L

9 = R E F E R E N C E S T O R E

3 Key in "3".

The items listed above will be adjusted automatically. Upon completion of the automatic adjustment, a completion message will appear on the LCD.

(Display example)

Completed []

After 5 seconds or so, the LCD will restore the display shown in step 2.

Discontinuing auto setup operation

To discontinue auto setup operation before completion, press the CANCEL button. The operation will be discontinued and an "Operation break" message will appear in the bottom line of the LCD.

(Display example)

AUTO SETUP <LEVEL> B-chbreak Operation

After 5 seconds or so, the LCD will restore the display shown in step 2.

If an auto setup error occurs

If an error is detected during auto setup, the operation will be discontinued and an error message will appear on the LCD. To erase the error message, press a button on the panel.

The procedure for storing the reference file differs depending on whether an ID code has been set.

When no ID code has been set

- 1 Light the orange lamp by pressing the SELECT button.
- 2 Turn on the AUTO SETUP button.
 The display shown below will appear on the LCD.

AUTO SETUP SELECT

I = W H I TE 2 = B L A C K

3 = L E V E L

9 = R E F E R E N C E S T O R E

3 Key in "9".

The reference file will be updated and stored. Upon completion of the reference file storing, the display shown below will appear on the LCD.

(Display example)

After 5 seconds or so, the LCD will restore the display shown in step 2.

When an ID code has been set

- 1 Light the orange lamp by pressing the SELECT button.
- 2 Turn on the AUTO SETUP button.
 The display shown below will appear on the LCD.

A U T O S E T U P S E L E C T

I = W H I T E 2 = B L A C K

3 = L E V E L

9 = R E F E R E N C E S T O R E

3 Key in "9".

The display for ID code setting will appear on the LCD as shown below.

REFERENCE STORE

ID CODE ?

4 Key in the ID code that has been set.

The ID code entered will appear on the LCD and the reference file will be updated and stored. Upon completion of the reference file storing, a completion message will appear on the LCD as shown below.

REFERENCE STORE

Completed!!

After 5 seconds or so, the LCD will restore the display shown in step 2.

If a wrong ID code is entered

If a wrong ID code is entered in step 4, a message to that effect will appear on the LCD.

(Display example)

REFERENCE STORE

ID CODE 12 NG!

Make sure of the correct ID code and key it in.

Discontinuing the reference file storing operation

To discontinue the reference file storing operation before completion, press the CANCEL button.

The operation will be discontinued and an "Operation break" message will appear in the bottom line of the LCD.

(Display example)

REFERENCE STORE

Gamma BAL: B—ch

Operation break

After 5 seconds or so, the LCD will restore the display shown in step 2.

If a reference file storing error occurs

If an error is detected during reference file storing, the operation will be discontinued and an error message will appear on the LCD.

To erase the error message, press a button on the panel.

- 1 Light the orange lamp by pressing the SELECT button.
- 2 Turn on the GAMMA button.
 The display on the LCD will change into the one for gamma value selection.

(Display example)

♦: Indicates the gamma value setting.

0=ON: Indicates that entering "0" will turn on the gamma circuit. (Entering "0" with "0=OFF" displayed will turn off the gamma circuit.)

3 Key in the number (1, 2, or 3) corresponding to the desired gamma value. When a number listed above is entered, the "♦" on the display moves to that number to indicate the updated gamma setting. If desired, you can enter another number to change the setting again.

Using the SWITCH button of the remote control panel, you can switch on and off the following control circuits of the camera:

- Auto knee circuit for automatically adjusting the knee point according to the high-light content of the picture
- Knee compensation circuit
- Detail circuit for detail correction
- · Linear matrix circuit for faithful color reproduction
- 1 Light the orange lamp by pressing the SELECT button.
- Turn on the SWITCH button.
 The first page of the display for circuit selection will appear on the LCD.

(Display example)

- •: Indicates the circuit currently being on.
- 3 Key in the number corresponding to the circuit to be switched on or off. Entering a number which is preceded by "◆" on the display switches off the corresponding circuit; entering a number which is not preceded by "◆" on the display switches on the corresponding circuit.
 - 1: atKNEE (Auto knee circuit)
 - 2: KNEE (Knee compensation circuit)
 - 3: DETAL (Detail circuit)
 - 4: MATRIX (Linear matrix circuit)
 - 5: ----- (No circuit assigned)
 - 6: ---- (No circuit assigned)
 - 7: ----- (No circuit assigned)
 - 8: next PG (Displaying the second page)*

^{*} If "8" is entered, the second page of the display for circuit selection will appear. You cannot use the second page unless an optional circuit board is installed in the camera control unit. For details in this regard, refer to the operation and maintenance manual for the camera control unit.

The remote control panel has the following special functions:

- Clearing all painting data (resetting the basic setup state).
- Selecting a gamma waveform or a staircase waveform for use as a test signal in the camera).
- Setting an ID code or changing the ID code already set (See page 1-16(E).)
- Deleting one or all scene files.

Clearing painting data/selecting test waveform

- 1 Light the orange lamp by pressing the SELECT button.
- 2 Turn on the SYSTEM button. The display for function selection will appear on the LCD as shown below.

0 = ALL PAINT CLEAR

1 = TEST 1/2 SELECT → 1

2 = ID REGISTRATION

3 = SCENE FILE DELETE

- **3** Key in a number corresponding to the function to be performed.
 - 0: Clearing all painting data
 - 1: Selecting a test signal

Every time "1" is keyed in, TEST1 (gamma waveform) or TEST2 (staircase waveform) is selected alternately. The number preceded by " \rightarrow " on the display indicates the test waveform

currently selected.

→1: TEST1 (gamma waveform)

→2: TEST2 (staircase waveform)

Deleting one or all scene files

- 1 Light the orange lamp by pressing the SELECT button.
- 2 Turn on the SYSTEM button.

0 = ALL PAINT CLEAR

1 = TEST 1 / 2 SELECT → 1

2 = ID REGISTRATION

3 = SCENE FILE DELETE

3 Key in "3".

SCENE FILE DELETION

0 = ALL 1 = ONE

4 To delete all scene files

1) Key in "0".

The LCD will show a message "ALL SCENES DELETING?".

At the same time, the CANCEL and CLEAR button will flash.

2) To delete all scene files: Press the CLEAR button.

To avoid deleting: Press the CANCEL button.

After 5 seconds or so, the LCD will restore the display shown in step 2.

To delete one scene file

1) Key in "1".

The LCD will change to the one for entering the scene file number you wish to delete.

2) Key in the desired file number.

The number entered will appear on the LCD.

- Press the CLEAR button.
 - When the specified scene file exists:

The LCD will show a message "SCENE FILE DELETING?".

At the same time, the CANCEL and CLEAR button will flash.

To delete the file: Press the CLEAR button.

To avoid deleting: Press the CANCEL button.

- When the specified scene file does not exist:

The LCD will show a message "File not exists!".

After 5 seconds or so, the LCD will restore the display shown in step 3.


To cancel scene file deleting

Press the CANCEL button.

After 5 seconds or so, the LCD will restore the display shown in step 2.

1-4-2. Manual Adjustment

You can manually adjust the setup items using the buttons and control knobs in the manual adjustment block. The manual adjustment procedure is as follows:



1 Press the item selector button for the item to be adjusted manually. The LCD will indicate the selected item in the bottom line and its current values will appear on the LED displays. (LCD display example: The WHITE button has been turned on to adjust the white balance manually.)

(Example of indications on the LED displays)

(From left to right, +5%, -10% and +7%, corresponding to R, G, and B)

2 Adjust the values as required by turning the control knobs below the respective LED displays.

The manually adjustable items are listed in the following table along with relevant information such as the names of the item selector buttons, the adjustable ranges, the item indications to appear on the LCD, and the ranges of adjustment values (in percent with respect to the adjustable range) to be indicated on the LED displays.

••	Button	Adjustable	Item display on LCD		
Item name name		range	LED	indication*	range
R, G, B white balance	WHITE :	ាន ១០១៩១០១៩១១ ១០១១៤១១ <u>១</u> ៦១		« WHITE »	
		±5.5 dB	±99%	±99%	±99%
R, G, B black balance			h skirkir	« BLACK »	
	BLACK	±20 IRE	±99%	±99%	±99%
R, G, B flare balance	FLARE	<u>Nik (1974) (1974)</u> - ±10 IRE (1977) - 1984 - Nogele	je 1900.	« FLARE »	
			± 99%	±99%	±99%
R, G, B gamma balance	GAMMA	±0.03	,1 - 4	« GAMMA »	>
			±99%	±99%	±99%
Detail level Detail limiter Crisping	DETAIL	0 to +10 dB	LEVEL	LIMTER	CRIS
			±99%	±99%	0 to +99%
Master gamma		±0.03	M.GAM	M.KNEE	M.SLO
	KNEE	± 15% ± 10%	±99%	±99%	±99%
R, G, B vertical modulation	V MOD	± 15%		« V MOD »	
			±99%	±99%	±99%
SC and H phases	PHASE	See	1-3-2 "Initia	I Adjustmen	t.''

^{*} The "+" and "%" do not appear on the LED displays.

To adjust the selected item after setting its current value as the zero point, proceed as follows:

- 1 Turn on the item selector button for the desired item.

 The LCD will indicate the selected item in the bottom line and its current values will appear on the LED displays.
- 2 Turn on the OFFSET button.

 The indications on the three LED displays will become "0", indicating that the offset adjustment mode has been entered.
- 3 Adjust the values as required by turning the control knobs below the respective LED displays.

The values indicated on the LED displays represent the amount of manual adjustment carried out after the OFFSET button was turned on.

To reset the offset adjustment mode, turn off the OFFSET button by pressing it again. The LED displays will return to the ordinary (absolute) mode.
 For example, if an adjustment value of "10"% indicated on an LED display in absolute mode is adjusted by "-5"% in offset mode, the LED display will read "5"% when the offset mode is reset.


Clearing the manual adjustment

Using the following procedure, you can clear the results of manual adjustment to obtain the initial unadjusted value (in the case of the white balance or black balance, the value obtained by automatic adjustment):

- 1 Press the CLEAR button. It will start flashing.
 (If you press the flashing CLEAR button again, it will go out and the clearing operation will be discontinued.)
- 2 Turn on the item selector button for the desired item.
 The CLEAR button that has been flashing will go off and the selected item will be reset to the initial unadjusted value.

1-4-3. Iris and Master Black Adjustment


Automatic iris adjustment



- 1 Place the IRIS control lever (RCP-3730) or knob (RCP-3731) in its central position.
- Turn on the AUTO IRIS button.
 The iris will be adjusted to an optimum value according to the amount of input light.

Adjusting the reference value for automatic iris adjustment

You can adjust the reference value for automatic iris adjustment in the range of $\pm 1F$ by adjusting the IRIS control lever or knob in the automatic adjustment mode, that is, with the AUTO IRIS button lit.



Setting the adjustable range

- 1 If the AUTO IRIS button is lit, turn it off.
- 2 Place the IRIS control lever (RCP-3730) or knob (RCP-3731) in its central position.
- 3 With the IRIS COARSE control knob, determine the center of the adjustable range for the IRIS control lever or knob.
- 4 Fully move the IRIS control lever (RCP-3730) or knob (RCP-3731) in both directions and make sure of the adjustable range.

If it is necessary to widen or narrow the adjustable range, adjust the SENS adjustment screw with a screwdriver (turning it clockwise narrows the adjustable range).

Adjustment

Adjust the IRIS control lever or knob so that an optimum picture is obtained.

You can adjust the master black using the master black control ring (RCP-3730) or MASTER BLACK control knob (RCP-3731). When the ring is turned, the master black indicator moves, giving an approximate indication of the adjusted master black value. The precise value is indicated in percent (-99% to +99%) in the MASTER BLACK display window.

Absolute mode and relative mode

The IRIS control lever and the master black control ring of the RCP-3730 and the IRIS control knob and the MASTER BLACK control knob of the RCP-3731 work in absolute mode with the RELATIVE button off or in relative mode with the RELATIVE button on.

Absolute mode: The positions of the controls absolutely correspond to the adjustment

values. Their central position always represents the central value of

the adjustable range.

Relative mode: The positions of the controls do not absolutely correspond to the adjustment values. Their central position does not necessarily

represent the central value of the adjustable range. The control position assumed when the RELATIVE button is turned on (when the relative mode is entered) becomes the reference position for the

subsequent adjustment in relative mode.

Note

If the AUTO IRIS button is turned off (to switch from the automatic to the manual adjustment mode) while the RELATIVE button is off (absolute mode), the iris is instantaneously adjusted to the value corresponding to the current position of the IRIS control lever (RCP-3730) or knob (RCP-3731). This may result in an abrupt change in picture brightness depending on the position of the lever or knob. You can prevent such an undesirable effect of switching from the automatic to the manual adjustment mode by turning on the RELATIVE button in advance. This is because when the AUTO IRIS button is turned off with the RELATIVE button on, the automatically adjusted iris value that was effective immediately before the automatic-to-manual switching is retained regardless of the position of the IRIS control lever or knob.

1-4-4. File Operation


You can create, store, and recall setup files and scene files using the file operation buttons and numeric keys. (For the procedure for storing the reference file, see page 1-26(E).)

Note

- File operation is not performable if any button is lit in the function select switch block ②. Turn it off in advance.
- If a file operation error occurs, an error message appears in the bottom line of the LCD. The LCD then restores an ordinary display (see page 1-18(E)) after 5 seconds or so.

Setup file operation

A. Storing a setup file



The procedure for storing the current adjustment data in a setup file differs depending on whether an ID code has been set.

When no ID code has been set

1 Turn on the SETUP button.

The display on the LCD will change into the one for entering a setup file number.

(Display example)

2 Key in the desired file number (1 to 8)*.

The number entered will appear on the LCD.

(Display example: Setup file number 1 has been entered.)

If the number just entered is wrong, you can enter the correct number immediately.

- * If you advance to step 3 after entering the number of an existing setup file, the setup file will be overwritten. (See "When an existing setup file is specified" on page 1-40(E).)
- **3** Press the STORE button.

The current setup adjustment values will be stored in the setup file of the specified number. At the same time, the setup file number indicated in the first line of the LCD will be updated.

(Display example: Setup file 1 has been stored.)

After 5 seconds or so, the LCD will restore an ordinary display.

When an ID code has been set

1 Turn on the SETUP button.

The display on the LCD will change into the one for entering a setup file number.

(Display example)

2 Key in the desired file number (1 to 8)*.

The number entered will appear on the LCD.

(Display example: Setup file number 1 has been entered.)

If the number just entered is wrong, you can enter the correct number immediately.

* If you carry out steps 3 and 4 after entering the number of an existing setup file, the setup file will be overwritten. (See "When an existing setup file is specified" on page 1-40(E).)

3 Press the STORE button.
The display on the LCD will change into the one for entering the ID code.

(Display example)

Key in the 2-digit ID code that has been set.

The ID code entered will appear on the LCD. When it is found correct, the current setup adjustment values will be stored in the setup file of the specified number. At the same time, the setup file number indicated in the first line of the LCD will be updated. The LCD will then restore an ordinary display after 5 seconds or so.

If a wrong ID code is entered

If a wrong ID code is entered in step 4, a message to that effect will appear on the LCD.

(Display example: "12" entered as the ID code was wrong.)

Make sure of the correct ID code and key it in.


When an existing setup file is specified

If you carry out the procedure for storing a setup file after specifying the number of an existing setup file, the specified setup file will be overwritten, causing the adjustment values that has been in the setup file to be replaced with the current adjustment values. If an existing setup file is overwritten by mistake, press the CANCEL button before proceeding with file operation any further. The LCD will show a message "Command CANCELLED!" and the previous contents of the setup file will be restored.

(Display example: After setup file 1 was overwritten, the overwriting was canceled.)

After 5 seconds or so, the LCD will restore an ordinary display.

B. Recalling a setup file



Turn on the SETUP button.

The display on the LCD will change into the one for entering a setup file number.

(Display example)

2 Key in the desired file number (1 to 8). The number entered will appear on the LCD.

(Display example: Setup file number 3 has been entered.)

If the number just entered is wrong, you can enter the correct number immediately.

3 Press the RECALL button.

The specified setup file will be recalled and the setup file number indicated in the first line of the LCD will be updated.

(Display example: Setup file 3 has been recalled.)

After 5 seconds or so, the LCD will restore an ordinary display.

If the specified setup file does not exist

A message "File not found!" will appear on the LCD and the recalling of the specified setup file will be discontinued.

(Display example: Setup file number 3 was specified, but the file was not found.)

After 5 seconds or so, the LCD will restore an ordinary display.

If a wrong setup file is recalled


Press the CANCEL button before proceeding with file operation any further. The LCD will show a message "Command CANCELLED!" and the settings that existed before the recall of the wrong setup file will be restored.

(Display example: After setup file 3 was recalled, the recall was canceled.)

After 5 seconds or so, the LCD will restore an ordinary display.

A. Storing a scene file

To store the adjustment data prepared for a particular scene in a scene file, use the following procedure:



Turn on the SCENE button.

The display on the LCD will change into the one for entering a scene file number.

(Display example)

2 Key in the desired file number (001 to 999). The number entered will appear on the LCD.

(Display example: Scene file number 112 has been entered.)

SS:
$$| 0 0 0$$
 SET = 2 SCN 2 4 2
+ $| 8 d B$ ND = $| C C = A$ \downarrow 2 4 3
Scene No. 0 0 2
 $<<$ WHITE $>>$

If the number just entered is wrong, you can enter the correct number immediately.

Note

When entering a 1- or 2-digit scene file number for the first time in step 2, you may enter the number as it is. However, when correcting a wrong number entered in step 2, enter the correct number as a 3-digit number by prefixing "0" or "00" to it as required.

When the specified scene file does not exist

A scene file assigned the specified number will be created, and the current adjustment values will be stored in it. At the same time, the scene file number indicated in the first line and the next scene file number preceded by "\u224" in the second line of the LCD will be updated.

(Display example: Scene file 112 has been stored and the next scene file number has been updated to 113.)

After 5 seconds or so, the LCD will restore an ordinary display.

When the specified scene file already exists

A message "File already exists!" will appear on the LCD. At the same time, the STORE and the CANCEL buttons will flash to urge the operator to enter a different number.

(Display example: Scene file number 112 was specified, but a scene file of the same number already exists under the same setup file.)

```
SS: 1000 SET = 2 SCN242
+ 18dB ND=1 CC=A \ \ 243
\rightarrow Scene No. 112 Store
File already exists!
```

To write over the specified scene file, press the STORE button. To avoid overwriting, press the CANCEL button.

Even if an existing scene file is overwritten by mistake, press the CANCEL button before proceeding with file operation any further. The LCD will show a message "Command CANCELLED!" and the contents of the scene file that existed before being overwritten will be restored.

(Display example: After scene file 112 was overwritten, the overwriting was canceled.)

After 5 seconds or so, the LCD will restore an ordinary display.

When eight scene files already exist


You can create up to eight scene files under each setup file. If you press the STORE button in step 3 after specifying a ninth scene file number in step 2, a message "Scene file full!" will appear on the LCD and the operation will be discontinued.

(Display example: Scene file number 112 was specified, but it has turned out that eight scene files already exist under setup file 2.)

$$SS: 10000$$
 $SET=2$ $SCN242$
+ $18dB$ $ND=1$ $CC=A$ $\downarrow 243$
> $Scene$ No. | 12 Store
Scene file full!

After 5 seconds or so, the LCD will restore an ordinary display.

B. Recalling a scene file



1 Turn on the SCENE button.
The display on the LCD will change into the one for entering a scene file number.

(Display example)

2 Key in the desired file number (001 to 999). The number entered will appear on the LCD.

(Display example: Scene file number 112 has been entered.)

If the number just entered is wrong, you can enter the correct number immediately.

Note

When entering a 1- or 2-digit scene file number for the first time in step 2, you may enter the number as it is. However, when correcting a wrong number entered in step 2, enter the correct number as a 3-digit number by prefixing "0" or "00" to it as required.

3 Press the RECALL button.

The specified scene file will be recalled. At the same time, the scene file number indicated in the first line and the next scene file number preceded by " \downarrow " in the second line of the LCD will be updated.

(Display example: Scene file 112 has been recalled and the next scene file number has been updated to 113.)

After 5 seconds or so, the LCD will restore an ordinary display.

When the specified scene file does not exist

A message ¹:File not found!'' will appear on the LCD and the operation will be discontinued.

(Display example: Scene file number 112 was specified, but the file was not found.)

After 5 seconds or so, the LCD will restore an ordinary display.

If a wrong scene file is recalled

Press the CANCEL button before proceeding with file operation any further. The LCD will show a message "Command CANCELLED!" and the settings that existed before the recall of the wrong scene file will be restored.

(Display example: After scene file 113 was recalled, the recall was canceled.)

After 5 seconds or so, the LCD will restore an ordinary display.

Recalling the next scene file

You can recall the next scene file indicated following "↓" in the second line of the LCD just by pressing the NEXT button in step 2 without entering any file number. In this case, step 3 is not required.

Note

If you press the NEXT button in step 2 while the next scene file does not exist (no file number is indicated following "\" on the LCD), a message "File not found!" will appear on the LCD and the operation for recalling the next scene file will be discontinued.

(Display example)

SS:
$$1000 \text{ SET} = 2 \text{ SCN 2 4 2}$$

+ $18 \text{ dB} \text{ ND} = 1 \text{ CC} = \text{A} \downarrow ---$
> Scene No. Next
File not found!

After 5 seconds or so, the LCD will restore an ordinary display.

1-4-5. Messages Displayed on the LCD

The principal messages that may be displayed on the LCD are listed in the following tables:

Messages related with file operation

Message	Meaning
File not found!	The specified file is not found.
File already exists!	The file of the specified number already exists.
Command CANCELLED!	The preceding command was canceled.
Scene file full!	Eight scene files already exist.
Key input error!	The key input was invalid.
Setup No. * Store	Setup file * has been stored.
Setup No. * Recall	Setup file * has been recalled.
Scene No. * * * Store	Scene file * * * has been stored.
Scene No. * * * Recall	Scene file *** has been recalled.

Messages related with auto setup or reference file storing

Message	Meaning
Completed!!	Execution of the command has been completed.
ID CODE ** NG!	The ID code entered was wrong.
Operation break	The operation was discontinued.
NEW ID CODE ** Store	ID code ** has been stored.
ID code erased	The ID code was erased.
Overflow	The adjustment range permitted for auto setup was exceeded.
Low level	The video level is too low.
Time limit	The auto setup operation did not end within the time limit.
Not closed	The iris cannot be closed.
Not opened	The iris cannot be opened.

Messages related with self-diagnosis performed on other equipment

Message	Meaning
RAM lost	The RAM of the camera head is defective.
CHU * * NG	The board (**) in the camera head is defective.
CCU * * NG	The board (**) in the camera control unit is defective.

Specifications

I/O Connectors

CCU connector (16-pin)

PREVIEW connector (6-pin)

Power supply

30 V DC 5 W

Power consumption

200 m (656 feet 51/2 inches)

Maximum cable length

(CCA-2 cable or equivalent)

Weight

RCP-3730: Approx. 2.5 kg (5 lb 8 oz)

RCP-3731: Approx. 2.3 kg (5 lb 1 oz)

Dimensions (w/h/d, including

RCP-3730: Approx. 102 × 376 × 127 mm

projecting parts)

 $(4^{1}/_{8} \times 14^{7}/_{8} \times 5 \text{ inches})$

RCP-3731: Approx. 102 × 376 × 84 mm

 $(4^{1}/_{8} \times 14^{7}/_{8} \times 3^{3}/_{8} \text{ inches})$

Accessories supplied

16-pin connectors (2)

6-pin connector (1)

Number plate (1 set)


Accessories not supplied

Operation and maintenance manual (1) CCA-2-30 camera connecting cable

Design and specifications are subject to change without notice.

第2章 設 置

2-1. 開梱と再梱包




2-2. 標準附属品

プレビューコネクター (6ピン): 1セット PREVIEWボタンのON/OFFの信号をスイッチャーへ伝達します。





ナンバープレート: 1シート



CCUコネクター (16ピン): 2セット CCU-370のRCPコネクターに接続します。電源及びコントロール信号の受け渡をします。








注) カメラ接続ケーブルCCA-2-30(16ピンコネクター付き) は、別売りアクセサリーとなります。

2-3. 適合コネクター/ケーブル

2-3-1. コネクターの出力信号

• コネクターの入出力信号は、次の通りです。

CCU (16-pin)



(EXT VIEW)

PIN No. SIGNAL SPECIFICATION 1 CABLE SHIELD ————————————————————————————————————			
2 GND ————————————————————————————————————		SIGNAL	SPECIFICATION
NC Non-connection	1	CABLE SHIELD	
4 NC Non-connection 5 NC Non-connection 6 CCU-RCP DATA (X) CCU SERIAL DATA 7 CCU-RCP DATA (Y) OUTPUT: 0.7 to 4.3Vp-p, 8 CCU-RCP DATA (G) Zo=68 Ω BALANCED 9 POWER (RCP) RCP POWER: +30V or +24V DC 10 GND (RCP) — 11 NC Non-connection 12 NC Non-connection 13 NC Non-connection 14 RCP-CCU DATA (X) RCP SERIAL DATA 15 RCP-CCU DATA (Y) INPUT: 0.7 to 4.3Vp-p,	2	GND	
5 NC Non-connection 6 CCU-RCP DATA (X) CCU SERIAL DATA 7 CCU-RCP DATA (Y) OUTPUT: 0.7 to 4.3Vp-p, 8 CCU-RCP DATA (G) Zo=68 Ω BALANCED 9 POWER (RCP) RCP POWER: +30V or +24V DC 10 GND (RCP) ——— 11 NC Non-connection 12 NC Non-connection 13 NC Non-connection 14 RCP-CCU DATA (X) RCP SERIAL DATA 15 RCP-CCU DATA (Y) INPUT: 0.7 to 4.3Vp-p,	3	NC	Non-connection
6 CCU-RCP DATA (X) CCU SERIAL DATA 7 CCU-RCP DATA (Y) OUTPUT: 0.7 to 4.3Vp-p, 8 CCU-RCP DATA (G) Zo=68 Ω BALANCED 9 POWER (RCP) RCP POWER: +30V or +24V DC 10 GND (RCP) ——— 11 NC Non-connection 12 NC Non-connection 13 NC Non-connection 14 RCP-CCU DATA (X) RCP SERIAL DATA 15 RCP-CCU DATA (Y) INPUT: 0.7 to 4.3Vp-p,	4	NC	Non-connection
7 CCU-RCP DATA (Y) 8 CCU-RCP DATA (G) 9 POWER (RCP) 10 GND (RCP) 11 NC Non-connection 12 NC Non-connection 13 NC Non-connection 14 RCP-CCU DATA (X) RCP SERIAL DATA 15 RCP-CCU DATA (Y) INPUT: 0.7 to 4.3Vp-p,	5	NC	Non-connection
8 CCU-RCP DATA (G) Zo=68 Ω BALANCED 9 POWER (RCP) RCP POWER: +30V or +24V DC 10 GND (RCP) — 11 NC Non-connection 12 NC Non-connection 13 NC Non-connection 14 RCP-CCU DATA (X) RCP SERIAL DATA 15 RCP-CCU DATA (Y) INPUT: 0.7 to 4.3Vp-p,	6	CCU-RCP DATA (X)	CCU SERIAL DATA
9 POWER (RCP) RCP POWER: +30V or +24V DC 10 GND (RCP) ————————————————————————————————————	7	CCU-RCP DATA (Y)	OUTPUT: 0.7 to 4.3Vp-p,
9 POWER (RCP) +24V DC 10 GND (RCP) — 11 NC Non-connection 12 NC Non-connection 13 NC Non-connection 14 RCP-CCU DATA (X) RCP SERIAL DATA 15 RCP-CCU DATA (Y) INPUT: 0.7 to 4.3Vp-p,	8	CCU-RCP DATA (G)	Zo=68 Ω BALANCED
11 NC Non-connection 12 NC Non-connection 13 NC Non-connection 14 RCP-CCU DATA (X) RCP SERIAL DATA 15 RCP-CCU DATA (Y) INPUT: 0.7 to 4.3Vp-p,	9	POWER (RCP)	
12 NC Non-connection 13 NC Non-connection 14 RCP-CCU DATA (X) RCP SERIAL DATA 15 RCP-CCU DATA (Y) INPUT: 0.7 to 4.3Vp-p,	10	GND (RCP)	
13 NC Non-connection 14 RCP-CCU DATA (X) RCP SERIAL DATA 15 RCP-CCU DATA (Y) INPUT: 0.7 to 4.3Vp-p,	11	NC	Non-connection
14 RCP-CCU DATA (X) RCP SERIAL DATA 15 RCP-CCU DATA (Y) INPUT: 0.7 to 4.3Vp-p,	12	NC	Non-connection
15 RCP-CCU DATA (Y) INPUT: 0.7 to 4.3Vp-p,	13	NC	Non-connection
	14	RCP-CCU DATA (X)	RCP SERIAL DATA
16 RCP-CCU DATA (G) BALANCED	15	RCP-CCU DATA (Y)	INPUT: 0.7 to 4.3Vp-p,
	16	RCP-CCU DATA (G)	BALANCED

PREVIEW (6-pin)



(EXT VIEW)


RCP-3730

PIN No.	SIGNAL	SPECIFICATION
1	NC	Non-connection
2	SW-2	30V DC max 0.1mA
3	NC	Non-connection
4	SW-1	30V DC max 0.1mA
5	NC	Non-connection
6	NC	Non-connection

RCP-3731

PIN No.	SIGNAL	SPECIFICATION
1	LED (+)	5V DC max 1mA
2	SW-2	30V DC max 0.1mA
3	LED (–)	5V DC max 1mA
4	SW-1	30V DC max 0.1mA
5	NC	Non-connection
6	NC	Non-connection

PREVIEWコネクター結線図




2-3-2. 接続コネクター

設置時、サービス時等において、コネクターパネル部の各種コネクターにケーブルを接続する際には、その先端に次に記するコネクター又は、同等品を使用して下さい。

コネクタ ー機能名称		接続するケーブル側のコネクターの部品番号および名称	
PREVIEW	(6P, FEMALE)	1-560-691-11	PLUG, CONNECTOR 6P MALE
ccu	(16P, FEMALE)	1-564-970-11	CONNECTOR, MULTI (SQUARE) 16P MALE or CABLE ASSEMBLY CCA-2-30 (200 m) 16P

CCU-370と本パネルは、別売りのカメラ接続ケーブルCCA-2-30を使用します。これ以外のケーブルをお使いになる時は付属の16ピンコネクターを使って、下図のように配線して下さい。ケーブルの最大長は200mまでです。 ※ケーブルの両端とも同じ接続



AWG-24シードル付 ツイストペアー線3組 外周シールド付ケーブル

2-4. 設置使用環境

本機は、カメラコントロールユニットCCU-370のRCPコネクターに接続し、調整卓に組み込んで使うことができます。 その際下記の環境内での使用に適応します。

• 動作周囲温度

0℃~45℃

• 保存温度

-25°C~+50°C

• 湿度

結露状態に置かないこと。

- 高温の部屋や熱源の近くは避けること。
- •電源などの発熱体の上に置かないこと。


2-5. 設置スペース

2-5-1. 設置条件

• コネクターパネルの後方に約7 cm以上の空間を設けること。(ケーブルの損傷を防ぎます。)


2-5-2. 外形寸法 (単位 mm)


RCP-3730




RCP-3730/3731

RCP-3731







2-6. 基板内スイッチの機能

MPU-56 基板

S1-1 (SHUTTER SPEED)

ON: PAL

OFF: NTSC

S1-2 (KNEE RGB CONTROL)

ON: 可能 OFF:不可能

S1-3 (CONTRAST & SATURATION)

ON: 可能

OFF: 不可能

S1-4 (EDTV CONTROL)


ON: 可能 OFF:不可能

S2

全てON: 起動時パネル自己診断開始 全て OFF: ファイルストアIDコード無効


2桁のBCDコード:ファイルストアIDコード有効

2-7. システム接続



SECTION 2 INSTALLATION

2-1. PACKING AND UNPACKING




2-2. SUPPLIED ACCESSORIES

Preview connector (6-pin) × 1
 Transmits the PREVIEW button ON/OFF signal to the switcher.




• Number plate × 1



Operation and Maintenance manual ×1

CCU Connector (16-pin) × 2
 Connects to the RCP connector of the CCU-370, and provides connections for power supply and control signals.



Note: Camera connection cable CCA-2-30 (with 16-pin connector) is an optional accessory.

2-3. CONNECTORS AND CABLES

2-3-1. Connector Input/Output Signals

The main connector Input/Output signals are as follows.

CCU (16-pin)



(EXT VIEW)

PIN No.	SIGNAL	SPECIFICATION	
1	CABLE SHIELD		
2	GND		
3	NC	Non-connection	
4	NC	Non-connection	
5.	NC	Non-connection	
6	CCU-RCP DATA (X)	CCU SERIAL DATA	
7	CCU-RCP DATA (Y)	OUTPUT: 0.7 to 4.3Vp-p,	
8	CCU-RCP DATA (G)	Zo=68 Ω BALANCED	
9	POWER (RCP)	RCP POWER: +30V or +24V DC	
10	GND (RCP)		
11	NC	Non-connection	
12	NC	Non-connection	
13	NC	Non-connection	
14	RCP-CCU DATA (X)	RCP SERIAL DATA	
15	RCP-CCU DATA (Y) INPUT: 0.7 to 4.3		
16	RCP-CCU DATA (G)	TA (G) BALANCED	

PREVIEW (6-pin)



(EXT VIEW)


RCP-3730

PIN No.	SIGNAL	SPECIFICATION
1	NC	Non-connection
2	SW-2	30V DC max 0.1mA
3	NC	Non-connection
4	SW-1	30V DC max 0.1mA
5	NC	Non-connection
6	NC	Non-connection

RCP-3731

PIN No.	SIGNAL	SPECIFICATION
1	LED (+)	5V DC max 1mA
2	SW-2	30V DC max 0.1mA
- 3	LED (–)	5V DC max 1mA
4	SW-1	30V DC max 0.1mA
5	NC	Non-connection
6	NC	Non-connection

Note: The PREVIEW connector is wired as show in the diagram below, and controls the external video switcher.




2-3-2. Connectors

When cable with connectors are set to the respective connectors on the connector panel during installation or service, the specified or equivalent connectors with cables, or the specified cable assemblies should be used, these are listed as follows:

Connector function		Parts No. and name of connector with cable	
PREVIEW	(6P, FEMALE)	1-560-691-11	PLUG, CONNECTOR 6P MALE
CCU	(16P, FEMALE)	1-564-970-11	CONNECTOR, MULTI (SQUARE) 16P MALE or CABLE ASSEMBLY CCA-2-30 (200 m) 16P

Connection between the CCU-370 and the remote control panel can be made with the CCA-2-30 camera connecting cable which is optionally available. Or, if you wish to use cable other than this, make use of the supplied 16-pin connectors by wiring them as shown in the diagram below. The maximum cable length should be 200 m.

• Make the same connections at both ends of the cable.



Cable should contain three twisted pairs, each surrounded by AWG-24 shielded wire. These, in turn, should be surrounded by outer shield.

2-4. OPERATING ENVIRONMENT

The set can be connected to the RCP connector of the camera control unit CCU-370 and installed into the control console. The set should be operated in the following environments.

- Operating temperature
- 0°C to +45°C
- Storage temperature
- -25°C to +50°C
- Avoid exposing the set to rain or moisture.
- Avoid placing the set in hot places.
- Avoid placing the set near a heat source such as a power source.


2-5. INSTALLATION SPACE

2-5-1. Installation Conditions


Provide a space of 7 cm or more behind the connector panel. (This prevents cable breakdown.)


2-5-2. Outside Dimensions (mm)


RCP-3730



RCP-3731







2-6. FUNCTION OF SWITCHES ON PC BOARD

MPU-56 Board S1-1 (SHUTTER SPEED) ON: PAL OFF: NTSC S1-2 (KNEE RGB CONTROL)

ON: possible
OFF: impossible
S1-3 (CONTRAST & SATURATION)

ON: possible

OFF: impossible S1-4 (EDTV CONTROL) ON: possible


OFF: impossible

S2

ALL ON: The panel diagnostics starts at the moment the power is on. ALL OFF: The file store ID code is not available.

BCD code of two figures: The file store ID code is available.

2-7. SYSTEM CONFIGURATION




第3章 サービスインフォメーション

3-1. 主要部品の交換方法


3-1-1. 外装の外し方

- ① KNOBを3個外します。
- ② ねじ (+B 3×5) 2本を外し、RACK BRACKET (2)をそれ ぞれ外します。
- ③ SUB CHASSIS (B2)を止めているねじ (+B 3×5) 2本を外します。
- 4 ねじ(+B 3>5)4本を外すとPANEL ASSY(J2)が外れます。 ねじ(+B 3>5)4本を外すとPANEL ASSY(D2)が外れます。 (RCP-3731のみ)
- ⑤ DSP-27基板のコネクターCN1を外します。 (RCP-3730のみ)DSP-28基板のコネクターCN1を外します。 (RCP-3731のみ)
- SW-402基板のコネクターCN5とMPU-56基板のコネクターCN4を外します。
- ⑦ ねじ (+B 3×5) 4本を外しCONTROL PANEL (B2) を外します。




3-1-2. ジョイスティックボリュームの交換方法 (RCP-3730のみ)


1. ねじ (PRECISION+P 2.6×6) 1本を外し、COVER TUBE を外します。




2. COVER FEXED SHAFTを外します。ねじ(SETSCREW 2.6×3)1本を外し、ADJUSTMENT TUBEを外します。




ボリュームを止めているナット及びねじ (SETSCREW 2.6x3) 2本を外し、VR FIXED TUBEを外します。



4. ボリュームに接続しているハーネスの半田付けを外します。



 CONTROL PANEL (J2) を外すときは、ねじ (SET-SCREW 2. 6公) 2本を外し、LEVER FIXED TUBE を外します。



6. 取り付けは取り外しと逆の手順で行います。


3-1-3. コントロールパネルの外し方


[RCP-3730]

- ① 3-1-2.ジョイスティックボリュームの交換方法を参 照してジョイスティックASSYを外します。
- ② ねじ (+B 3×5) 2本を外してCOVER (S)を外します。
- ③ ねじ(+B 3×5)4本を外してCONTROL PANEL(J2) を外します。

[RCP-3731]

- ① KNOB 2個を外します。
- ② ねじ (+B 3×5) 2本を外してCOVER (S)を外します。
- ③ ねじ(+B 3×5)4本を外してCONTROL PANEL (D2) を外します。





3-2. サービス上の注意事項

3-2-1. PROM IC

PROM ICにはオリジナル品名の末尾にそのプログラムの名 称が記載されています。

又、バージョン変更された場合、この末尾の名称が変わり ます。オリジナル品名のみ (プログラム化されていない) は 絶対に使用しないこと。

尚、各基板に使われているICは全てソケット化しています。

3-2-2. 補修用部品の注意事項

(1) 安全重要部品

回路図、分解図、電気部品表中、 介印及び () で 囲まれた部品は安全性を維持するために重要な部品で す。従って、これらの部品を交換するには必ず指定の 部品と交換して下さい。

(2) 部品の共通化

ソニーから供給される部品はセットに実装されている ものと異なることがあります。これは部品の共通化、 改良等によるものです。分解図や電気部品表中には現 時点での共通化された部品が記載されています。

(3) 部品在庫

抵抗

分解図、電気部品表中、SP欄がSで示されている部品 は常時在庫しています。

SP欄が"O"で示されている部品は交換頻度が低い部品 であるので在庫しないことがあり、納期が長くなるこ とがあります。

(4) コンデンサ、インダクタ、抵抗の単位

: Ω


回路図、分解図、電気部品表中、特に明記したものを 除き、下記の単位は省略されています。

コンデンサ : μF インダクタ : μH 治工具

3-2-3.

ICテストクリップ

TC-16 ソニー部品番号 J-6041-770-A TC-20 ソニー部品番号 J-6041-780-A



チェック、調整時にDIPタイプICの足にオシロスコープの プローブをかけるのに便利です。


3-2-4. チップ部品交換時の注意事項

コンデンサー





ダイオード、トランジスタ



用意する工具: 20W程度の半田ゴテ(可能ならば、コテ

の温度が270±10℃にコントロールでき

る温度コントローラーを使用する。)

編組線(ソルダートール)

半田(0.6mm径のものが望ましい)

ピンセット

半田付け条件: コテ温度270±10℃

端子1か所を2秒以内に半田付けするこ

上。

手順

1. 抵抗又はコンデンサーを外す場合は、半田ゴテの先を チップ部品の上にのせて部品を加熱し、半田が溶けた 状態で横にずらして外します。

ダイオード又はトランジスターの場合は、チップ部品の片側に足が2本出ている方を同時に加熱し、半田が溶けたら部品を上に起こして足2本を外します。次にもう片方の足を外すようにします。

- 2. 外した後、ランド表面を平らにするために、編組線を 使って半田を吸い取って下さい。
- 3. 取り外した部分のパターンはがれ、隣接半田付け部の ダメージ、ブリッジなどがないことを目視にて確認し ます。
- 4. パターンにうすく予備半田します。
- 5. 新しいチップ部分をパターンにのせ両端を半田付けし ます。

取り外したチップ部品は再度使用しないこと。

詳しくは、 チップ・マニュアル ソニー部品番号9-963-089-01を参照して下さい。


SECTION 3 SERVICE INFORMATION

3-1. REPLACEMENT OF MAIN PARTS

3-1-1. Cabinet Removal


(D2). (only for RCP-3731)

- ① Remove three knobs.
- Remove two screws (+B 3x5) and remove RACK BRACKET(2) respectively.
- Remove two screws (+B 3x5) securing SUB CHASSIS (B2).
- Remove four screws (+B 3×5) and remove PANEL ASSY (J2). (only for RCP-3730)
 Remove four screws (+B 3×5) and remove PANEL ASSY
- Disconnect the connector CN1 on the DSP-27 board. (only for RCP-3730)
 Disconnect the connector CN1 on the DSP-28 board. (only for RCP-3731)
- 6 Disconnect two connectors, CN5 on the SW-402 board and CN4 on the MPU-56 board.
- Remove four screws (+B 3x5) and remove CONTROL PANEL (B3).




3-1-2. Replacement of Joystick Control (only for RCP-3730)


 Remove the screw (PRECISION +P 2.6x6) and remove COVER TUBE.




 Unscrew COVER FIXED SHAFT. Remove the setscrew (2. 6x3) and remove ADJUSTMENT TUBE.




3. Remove the nut securing the control and remove the setscrew (2.6×3). VR FIXED TUBE will be removed.



4. Desolder harness connected to the control.



5. When removing CONTROL PANEL (J2), remove two setscrews (2.6×3) and remove LEVER FIXED TUBE.




When mounting a new control, reverse the procedures for removal.

3-1-3. Removal of Control Panels


[RCP-3730]

- Remove joystick ASSY, referring to Section 3-1-2.
 Replacement of Joystick Control.
- ② Remove two screws (+B 3×5) and remove COVER (S).
- Remove four screws (+B 3×5) and remove CONTROL PANEL (J2).



[RCP-3731]

- Remove two knobs.
- 2 Remove two screws (+B 3×5) and remove COVER (S).
- Remove four screws (+B 3×5) and remove CONTROL PANEL (D2).



3-2. NOTE ON MAINTENANCE SERVICES

3-2-1, PROM IC

Each PROM IC on the PC board has a suffix to its original designation. This suffix may change according to improvement of IC. Never use an IC having no suffix to its original designation, because its memory has not been programmed. Each PROM IC is mounted to the PC board via socket.

3-2-2. Note On Replacement Parts

1. Safety Related on Components Warning

Components identified by shading marked with \triangle on the schematic diagrams, exploded views and electrical spare parts list are critical to safe operation. Replace these components with Sony Parts whose parts numbers appear as shown in this manual or in service manual supplements published by Sony.

2. Standardization of Parts

Replace Parts that are supplied from Sony Parts Center can sometimes have different shape and external appearance than what are actually used in equipment. This is due to "accommodating the improved parts and/or engineering changes" or "standardization of genuine parts."

- This manual's exploded view and electrical spare parts lists are indicating the parts numbers of "the standardized genuine parts at present."
- Regarding engineering parts and diagrams changes in our engineering department, refer Sony service bulletins and service manual supplements.

3. Stocked of Parts

The parts marked with "S" in the SP column of the exploded views and electrical spare parts list are normally required for routine service work. Order for parts marked with "O" will be proceed, but allow for additional delivery time.

4. Units of Capacitors. Inductors, and Resistors


The following units are omitted in the schematic diagrams, exploded views, and electrical parts lists unless otherwise specified;

 $\begin{array}{lll} \text{Capacitor} & : & \mu F \\ \text{Inductor} & : & \mu H \\ \text{Resistor} & : & \Omega \end{array}$

3-2-3. Fixture

IC Test Clip


TC-16 Sony Parts No. J-6041-770-A TC-16 Sony Parts No. J-6041-780-A




This clip is convenient for contacting an oscilloscope probe with each leg of DIP type IC when the IC is checked and adjusted.

3-2-4. Precaution on Replacement of Chip Parts






Resistor



Diode and Transistor



Tools required:

Soldering iron of approx. 20W
(Use a temperature controller, if possible, which can control the iron temperature to 270±10°C)
Braided wire (SOLDER TAUL)
Solder (A solder of 0.6mm in diameter is recommended.)
Tweezers
Soldering conditions:

Iron temperature of 270±10℃

A connector should be soldered within 2 seconds.

Do not reuse parts which have been removed.

For details, refer to CHIP COMPONENTS MANUAL, Sony's parts No. 9-972-289-91 prepared by Sony Corporation.

Procedures

pin on another side.

- (1) To remove a resistor or capacitor, place the tip of a soldering iron on chip parts to heat the parts, and then move it horizontally for removal while being desoldered.
 For removal of a diode or transistor, heat the one side, with two pins, of chip parts at the same time, set the parts up when
- (2) Absorb solder by using a braided wire to smooth the land surface of board after removal.

desoldered, and remove the two pins. And then, remove the


- (3) Confirm by visual check that no trace is come off, no adjacent parts is damaged or no bridging occur.
- (4) Perform a thin pretinning on the trace.
- (5) Place new chip parts on the trace to solder its both sides.

,


SECTION A DIAGRAMS

BOARD LAYOUT







RCP-3731



RCP-3730/3731



|B-RCP3730/3731-0VERALL/BLOCK| A-5 | A | B | C | D | E | F | G | H




MPU-56 BOARD SW-402 BOARD DPS-27 BOARD DPS-28 BOARD IR-12 BOARD LED-112 BOARD

RCP-3730 RCP-3731

(RCP-3731)

RCP-3730/3731



1-636-956-13 SOLDERING SIDE

1-636-956-13 1-636-956-13 COMPONENT SIDE

1-636-956-13 SOLDERING SIDE

MPU-56 (1-636-956-13) IC5 IC6 IC7 IC8 IC9 IC10 CN1 CN2 CN3 CN4 CN5 CN6 CN7 Q8 Q9 Q10 N-9 N-8 N-8 K-2 J-2 J-1 K-8 G-6 H-10 Q11 Q12 IC11 IC12 IC13 IC14 J-4 J-5 H-2 D-4 F-4 E-1 D-8 O-7 G-5 S2 S3 G-1 I-5 CN8 M-8 N-5 D1 D2 D3 D4 D5 D6 L-4 L-4 L-5 O-2 IC15 IC16 IC17 IC18 IC19 L-1 K-1 K-1 J-1 J-1 TP1 TP2 TP3 TP4 IC19 IC20 IC21 IC22 IC23 IC24 IC25 IC26 F-5 G-8 N-10 J-6 L-6 D10 D11 D12 D13 D14 D15 K-7 K-4 F-10 H-1 H-1 G-1 G-1 G-1 F-1 L-2 L-2 L-2 JR1 D16 D17 JR2 JR3 D18 PH1 N-4 E1 Q1 Q2 Q3 Q4 Q5 Q6 Q7 FB1 N-4 O-4 O-7 N-7 N-9 IC1 IC2 IC3 IC4 L-5 M-4


RCP-3730/3731

A-12

Α

A-11

FRAME WIRING (1/2)
MPU-56 BOARD



RCP-3730/3731

A-13

D

Ε

G

i.

Н


.5

•

-

.

п




5 K | L | M | N | O


.

P

DSP-27 BOARD (FOR RCP-3730)




1-632-788-11 COMPONENT SIDE 1-632-788-11 SOLDERING SIDE



1-632-788-11 COMPONENT SIDE 1-632-788-11 SOLDERING SIDE

IR-12 BOARD (FOR RCP-3730)



1-632-787-11 SOLDERING SIDE


LED-:






1-632-787-11 COMPONENT SIDE

DSP-28 BOARD (FOR RCP-3731)



1-632-789-11 COMPONENT SIDE 1-632-789-11 SOLDERING SIDE




1-632-789-11 COMPONENT SIDE 1-632-789-11 SOLDERING SIDE


1-636-955-11 COMPONENT SIDE 1-636-955-11 SOLDERING SIDE




1-636-955-11 SOLDERING SIDE



SW-402 BOARD



1-636-954-13 COMPONENT SIDE 1-636-954-13 SOLDERING SIDE



1-636-954-13 COMPONENT SIDE 1-636-954-13 SOLDERING SIDE

SW-402 (1-636-954-13) Q16 RV1 G-7 F-7 Q17 S-5 S-6 RV2 Q18 B-9 E-3 T-6 S2 S3 S4 S5 CN₅ Q21 D1 D2 D3 D4 D5 D6 D7 D8 D10 D11 D12 D13 D14 D15 D16 D17 D20 D21 D22 D23 D24 D26 D27 D28 D29 D30 D31 Q22 Q23 Q24 Q25 Q26 Q27 Q28 Q39 Q30 Q31 Q32 Q33 Q34 Q35 Q36 Q37 Q38 Q39 Q40 Q41 \$6 \$7 \$8 \$9 \$10 K-4 L-3 S11 S12 S13 S14 S15 S16 S17 N-7 N-7 S18 S19 S20 S21 S22 S23 Q42 Q43 Q44 Q45 Q46 Q47 Q48 Q51 Q52 Q53 Q54 Q55 Q55 Q56 Q57 Q58 Q60 Q61 Q62 Q63 Q64 Q65 Q66 Q67 Q68 Q69 Q70 Q71 S24 S25 S26 S27 S28 S29 S30 S31 S32 S33 S35 IC1 IC2 IC3 IC4 IC5 IC6 IC7 IC8 IC9 IC10 IC11 IC12 T-2 R-8 T-6 P-4 P-5 K-7 K-5 K-4 O-7 S39 S40 S41 S42 C-4 C-7 J-9 C-3 C-4 C-3 B-5 B-3 B-1 Q1 Q2 Q3 Q4 Q5 Q6 Q7 Q8 Q9 Q10 Q11 Q12 Q13 Q14 Q15 T-9 S-9 R-7 S-1 S-2 S-2 R-2 T-4 O-9 O-9 D-9 O-9 R-9 I-5 I-5 Q72 Q73 Q74

RCP-3730/3731

Q76

Q78 Q79 Q80 B-9 B-9

M-1

S-3

R-1 T-3

D-9 S-10

D-6 E-5 D-5

Q-10

Q-8

Q-6

Q-1

L-6 L-5 L-3 M-9

M-8

M-5

0-9

N-8 0-7


O-5 O-3 O-2

E-9


E-8 D-8

FRAME WIRING (2/2)

DSP-27 BOARD (FOR RCP-3730) DSP-28 BOARD (FOR RCP-3731) IR-12 BOARD (FOR RCP-3730) LED-112 BOARD SW-402 BOARD



A-21
A | B | C | D | E | F | G | H |



SECTION B SEMICONDUCTOR

TMP82C79M-2····· B-8
TMS27C256-20JL···· B-9

uPD4701AC B-9 uPD7004C B-10

PAGE


The circuit diagram of IC is obtained from the IC data book published by the manufacturer.

TYPE

The chedit diag-	
TYPE	PAGE
1SS226 · · · · · · · · · · · · · · · · · ·	B-2
2SA1162	B-2
2SC2712G ·····	B-2
2SD596	B-2
CXD1095Q	B-3
CXK5864BM-10L	B-4
DTA143XK	B-2
DTC143XK	B-2
GL-3HY8	B-2
HD64180ZF·····	B-4
HN58C65FP-25 ·····	B-5
LB-202ML	B-2 B-2
LD-001MG · · · · · · · · · · · · · · · · · · ·	B-2
MA152WK	B-2
MC14053BF MC74HC86F	B-5 B-5
RD ?? M-B ? · · · · · · · · · ·	· B-2
SLT-35DU SLT-35MG3	· B-2 · B-2
SN74HC02NS	· B-5 · B-6 · B-6 · B-6 · B-7
TC74HC574F ·····	В-7
TC7S00F TC7S04F TC7S32F	· B-7 · B-7 · B-7
TL7700CPS	· B-7
TLP112	B-2
TLUG164	· B-2


RCP-3730/3731 B-1

DIODE, TRANSISTOR




CXD1095Q (SONY) FLAT PACKAGE

C-MOS I/O PORT EXPANDER - TOP VIEW -



PIN NO.	IN	OUT	SYMBOL	PIN NO.	۱N	OUT	SYMBOL	PIN NO.	IN	ουτ	SYMBOL	PIN NO.	IN	оит	SYMBOL
			NC .	17	0	0	PC6	33			NC	49	0	0	PXO
2			NC	18	0	0	PC7	34			NC	50	0	0	PX1
3	0	0	PB1	19			NC	35	0	0	D3	51			NC
4	0	0	PB2	20	0	0	PDO	36	0	0	D4	52	0	0	PX2
5	0	0	PB3	21	0	0	PD1	37	0	0	D5	53	0	0	PX3
6	0	0	PB4	22	0	0	P02	38	0	0	06	54	0	0	PAQ
7	0	0	PB5	23	0	0	PD3	39	0	0	D7	55	0	0	PA1
8	0	0	PB6	24	0	0	PD4	40	0		CLR	56	0	0	PA2
9	0	0	P87	25			GND	41	0		RST	57			GND
10			GND	26	0		VDD (+5V)	42			GND	58	0		VDD(+5V)
11	0	0	PCO	27	0	0	PD5	43	0		WR	59	0	0	PA3
12	0	0	PC1	28	0	0	PD6	44	0		RD	60	0	0	PA4
13	0	0	PC2	29	0	0	PD7	45	0		. CS	61	0	0	PA5
14	0	0	PC3	30	0	0	DO	46	0		AO	62	0	0	PA6
15	0	0	PC4	31	Ö	0	DI	47	0		A1	63	0	0	PA7
16	0	0	PC5	32	0	0	D2	48	0		A2	64	0	0	PBO






cs	RD	WR	A2	A1	AO	MODE
0	0	1	0	0	0	PORT A DATA BUS
0	0	1	0	0	1	PORT B - DATA BUS
0	0	1	0	1	0	PORT C- DATA BUS
0	Ö	1	0	1	1	PORT D-DATA BUS
0	0	1	1	0	0	PORT X - DATA BUS
0	0	1	1	0	1	
0	0	1	1	1	0	
0	0	1	1	1	1	
0	1	0	0	0	0	DATA BUS-PORT A
0	1	0	0	0	1	DATA BUS -PORT B
0	1	0	0	1.	0	DATA BUS +PORT C
0	1	0	0	1	1	DATA BUS-PORT D
0	1.	0	1	0	0	DATA BUS-PORT X
0	1	0	1	0	1	
0	1	0	1	1	0	DATA BUS -CTL REG.1
0	1	0	1	1	1	DATA BUS +CTL REG.2
1"	×	X	×	×	X	DATA BUS ; HI-Z

O; LOW LEVEL
1; HIGH LEVEL
X; DON'T CARE
HI-Z, HIGH IMPEDANCE

DO-D7; DATA BUS INPUTS/OUTPUTS
CS; CHIP SELECT INPUT
RD; READ STROBE INPUT
WR; WRITE STROBE INPUT
AO-A2; ADDRESS INPUT
RST; RESET INPUT
CLR; CLEAR INPUT
PAO-PAT; PORT A INPUTS/OUTPUTS
PBO-PB7; PORT B INPUTS/OUTPUTS
POO-PO7; PORT O INPUTS/OUTPUTS
POO-PO7; PORT D INPUTS/OUTPUTS
PXO-PX3; PORT X INPUTS/OUTPUTS



A3 7

14 GND

CXK5864BM-10L (SONY) (ACCESS TIME = 100nS) FLAT PACKAGE C-MOS 64K(8192x8)-BIT STATIC RAM - TOP VIEW -

10 A0 9 A1 8 A2 7 A3 6 A4 5 A5 4 A6 3 A7 25 A8 24 A9 21 A10 23 A11 2 A12 V00 (+5V) 28 1 NC 1/0 1 1/0 2 1/0 3 1/0 4 15 1/0 5 16 1/0 6 17 1/0 7 19 1/0 8 27 WE A12 2 26 CE 2 A7 3 25 A8 A6 4 24 A9 A5 5 23 A11 A4 6


22 OE

A2 8	21 A10	22 27 20 26
A1.9	20 CE 1	
A0 10	19 1/0 8	A0-A12 ; ADDRESS INPUT CE1, CE2 ; CHIP ENABLE IN
/01 11	18 1/0 7	I/O1-I/O8 ; DATA INPUT/OUT OE ; OUTPUT ENABLE
/02 12	17 1/06	WE ; WRITE ENABLE I
1/03 13	16 1/0 5	


CEI	CE2	OE	WE	MODE	I/O TERMINAL
7	X	X	X	NOT SELECT	HIGH IMPEDANCE
×	0	×	X	NOT SELECT	HIGH IMPEDANCE
0	Ť	i	1	OUTPUT DISABLE	HIGH IMPEDANCE
Ď	1	ō	1	READ	OUTPUT DATA
ň	1	Ι×	0	WRITE	INPUT DATA

15 1/0 4

0;LOW LEVEL 1;HIGH LEVEL X;DON'T CARE




HD64180ZF (HITACHI) FLAT PACKAGE C-MOS 8-BIT MICROPROCESSOR




PIN NO.	1/0	SYMBOL	PIN NO.	1/0	SYMBOL	PIN NO.	1/0	SYMBOL	PIN NO.	1/0	SYMBOL
1	-1	NM1	21	0	A11	41	1/0	D6	61	0	HALT
2	-	NC	22	-	NC .	42	-	NC	62	-	NC
3	_	NC	23	-	NC	43	-	NC -	63	-	NC
4	- 1	INTO	24	0	A12	44	1/0	D7	64	0	REF
5	T	INT1	25	0	A13	45	0	RTSO	65	0	ÎŌĒ
6	1	ĪNT2	26	0	A14	46	T	CTS0	66	0	ME
7	0	ST	27	0	A15	47	1	DCD0	67	0	Ε
8	0	- A0	28	Ö	A16	48	0	TXA0	68	0	LIR
9	0	A1	29	0	- A17	49		RXA0	69	0	WR
10	0	A2	30	-	NC ·	50	1/0	CKA0/DREQ0	70	0	RD
11	0	A3	31	0	A18/TOUT	51	-	NC	71	0	ф
12		Vss	32		VCC	52	0	TXA1	72		Vss
13	0	A4	33	0	- A19	53		TEST	73		Vss
14	_	NC	34		Vss	54	T	RXA1	74	1	XTAL
15	0	A5	35	1/0	D0	55	1/0	CKA1/TEND0	75	-	NC
16	0	A6	36	1/0	D1	56	0	TXS	76	1	EXTAL.
17	0	A7	37	1/0	D2	57		RXS/CTS1	77	1	WAIT
18	0	A8	38	1/0	D3	58	1/0	CKS	78	0	BUSACK
19	0	A9	39	1/0	D4	59	1	DREQT	79	1	BUSREC
20	0	A10	40	1/0	D5	60	0	TEND1	80	1	RESET


35	00	AC	8
36	Di	Ai	9
37			10
38	02	A2	11
39	03	A 3	13
40	D4	A 4	15
41	D5	A 5	16
44	D6	A6	17
44	D7	A7	_
		AB	18
10	NMI	A 9	19
4	INTO	A10	20
5	INT 1	A11	21
6	INT 2	A12	24
•	,	A 13	25
80	RESET	A 14	26
_	KESE!	A 15	27
	l		2B
	i	A 16	29
		A 17	31
	Α Α	18/TOUT	33
77		A19	<u> </u>
	TIAW		
		10E	65 66
		ME	D
		ε	67
		WR	69
		RD	70
79	BUSREO		
1		BUSACK	78
1		ST	[7
.		HALT	61
		REF	64
			68
50		LIR	P-
55	CKA O/DREGO		ļ
59	CKA 1/TENDO		60
<u></u> 9	DREQ 1	TEND1	ŏ
40			45
460 470	CTSO	RTSO	_
<u></u> -a	DCDO	TXAO	48
49	RXAO	-	
54	RXA1	TXA 1	52
57	RXS/CTS I	TXS	56
58	cks		
		i	
74	XTAL		
76	EXTAL	ø	71
1			

AO-A19; ADDRESS BUS (3-STATE) BUSACK; BUS ACKNOWLEDGE BUSREQ; BUS REQUEST CKAO,1; CLOCK FOR ASYNCHRONOUS SCI CHANNELO,1 CKS; CLOCK FOR SERIAL I/O PORT CTSO,1; CLEAR TO SEND FOR ASYNCHRONOUS SCI CHANNEL 0,1 CISCI CHANNEL 0,1
DO-D7; DATA BUS
DCD0; DATA CARRIER DETECT FOR
ASYNCHRONOUS SCI CHANNEL 0
DREQ0.1; DMA REQUEST FOR CHANNEL 0,1
E; ENABLE
EXTAL; EXTERNAL CLOCK
INTO-2; INTERRUPT 0-2
IOE; I/O ENABLE (3-STATE)
LIR; LOAD INSTRUCTION REGISTER
ME; MEMORY ENABLE(3-STATE)
NMI; NON-MASKABLE INTERRUPT
RO; READ
REF; REFRESH
RTSO; REQUEST TO SEND FOR ASYNCHRONOUS
SCI CHANNEL 0
RXAO,1; RECEIVE DATA FOR ASYNCHRONOUS SCI CHANNEL O
RXAO.1; RECEIVE DATA FOR ASYNCHRONOUS
SCI CHANNEL O,1
RXS; RECEIVE DATA FOR SERIAL I/O PORT
ST; STATUS
TENDO.1; TRANSFER END FOR CHANNEL O,1
TOUT; TIMER OUT
TXAO.1; TRANSFER DATA FOR ASYNCHRONOUS
SCI CHANNEL O,1
TXS; TRANSFER DATA FOR SERIAL I/O PORT
WR; WRITE(3-STATE)
Ø; SYSTEM CLOCK



HN58C65FP-25 (HITACHI) (ACCESS TIME = 250nS) C-MOS 64K (8192x8)-BIT EEPROM







CE	ŌΕ	WE	RDY BUSY	I/O TERMINAL	FUNCTION
0	0	1	HI-Z	Dout	READ
1	X	X	HI-Z	HI-Z	STANDBY
0	1	0	HI-Z → LOW	DIN	WRITE
Ö	1	1	HI-Z	HI-Z	DESELECT
×	X	1	HI-Z	-	WRITE INH
X	0	х	HI-Z	-	WRITE INH
	0	1	LOW	DATA OUT (L/O7)	DATA POLLING

MC14053BF (MOTOROLA) FLAT PACKAGE


C-MOS TRIPLE 2-CHANNEL ANALOG MULTIPLEXER/DEMULTIPLEXER – TOP VIEW –



MC74HC86F (MOTOROLA) FLAT PACKAGE C-MOS EXCLUSIVE OR GATE - TOP VIEW -




SN74HC02NS (TI) FLAT PACKAGE C-MOS QUAD 2-INPUT NOR GATE - TOP VIEW -




SN74HC04NS (TI) FLAT PACKAGE

C-MOS HEX INVERTER - TOP VIEW -




NOTE:	
TYPE	Vpo
74ACT04 TYPES 74HCT04 TYPES	+5∨
OTHER TYPES	+2V to +6V


SN74HC138NS (TI) (V $_{\rm DD}$ = +2 to +6V) FLAT PACKAGE C-MOS 3-TO-8 LINE DECODER/DEMULTIPLEXER - TOP VIEW -




SN74HC238NS (TI) FLAT PACKAGE C-MOS 3-TO-8 LINE DECODER/DEMULTIPLEXER - TOP VIEW -



SN74HC163NS (TI) (V $_{\infty}$ = +2 to +6V) FLAT PACKAGE C-MOS PRESETTABLE SYNCHRONOUS 4-BIT BINARY COUNTER - TOP VIEW -




COM		INP		MODE
RΦ	LD	EN1	EN2	
0	×	x	×	RESET (SYNCHRONOUS)
1	0	х	×	PRESET (SYNCHRONOUS)
1	1	0	Х	NO COUNT
1	1	X	0	NO COUNT
1	1	1 1	1	COUNT




COUNT SE	QUEN	CE						
COUNT		OUTPUTS						
COOK	QD	QÇ	QB	QA				
0	0	0	0	0				
1	0	0	0	1				
2	0	0	1	0				
3	0	0	1	1				
4	0	1	0	0				
5	0	1	0	1				
6	0	1	ŀ	0				
7	0	_ 1	1	1				
8	1	0	0	0				
9	1	0	0	1				
10	_ 1	0	1	0				
11	1	0	1	1				
12	1	1	0	0				
13	1	1	0	1				
14	-	1	1	0				
15	1	1	1	1				

SN74HC245NS (TI) FLAT PACKAGE.


C.MOS BILATERAL BUS TRANSCEIVERS WITH 3-STATE OUTPUTS — TOP VIEW —




SN74HC32NS (TI) FLAT PACKAGE C-MOS 2-INPUT OR GATE - TOP VIEW -




SN74HC573NS (TI) (V_{00} = +2 to +6V) FLAT PACKAGE C-MOS 3-STATE OUTPUTS OCTAL LATCHES - TOP VIEW -




TC74HC574F (TOSHIBA) (V_{∞} = +2 to +6V) FLAT PACKAGE C-MOS 3-STATE D-TYPE EDGE-TRIGGERED FLIP-FLOP - TOP VIEW -




TC7S00F (TOSHIBA) FLAT PACKAGE C-MOS 2-INPUT NAND GATE - TOP VIEW --



TC7S04F (TOSHIBA) FLAT PACKAGE C-MOS INVERTER - TOP VIEW -




TC7S32F (TOSHIBA) FLAT PACKAGE C-MOS 2-INPUT OR GATE - TOP VIEW -





TL7700CPS (TI) FLAT PACKAGE


VARIABLE SUPPLY VOLTAGE SUPERVISOR

- TOP VIEW -










uPD7004C (NEC)

CMOS 10-BIT SUCCESSIVE COMPARATOR TYPE A/D CONVERTER - TOP VIEW -




AO ; CONTROL ADDRESS INPUT
CHO~7; ANALOG INPUT
CODE ; CODE SELECT (2'S COMPLEMENT/
BINARY) INPUT
CS ; CHIP SELECT INPUT
DBO~7; DATA BUS INPUT/OUTPUT
DEVO

DBO-7; DAIA BUS DEVO, DEVO, DEVI; CLOCK RATE SELECT INPUT EOC ; CONVERSION ENDING SIGNAL OUTPUT MC ; MODE SELECT INPUT RD ; READ SIGNAL INPUT

SCKI SCKO SHIFT

; SERIAL CLOCK INPUT
; SERIAL CLOCK OUTPUT
; SHIFT SELECT (LS8 FIRST/
MS8 FIRST)
; SERIAL INPUT
; SERIAL OUTPUT ENABLE OUTPUT
; STADAESS WRITE STROBE SIGNAL
INPUT
; WRITE SIGNAL INPUT

SOEN STB



мс	MODE
0	SERIAL
1	PARALLEL

PAR	ALLE	L MO	DE	
cs	WR	RD	AO	MODE
1	X	х	X	HIGH IMPEDANCE
0	1	1	X	HIGH IMPEDANCE
0	0	1	0	*1 ANALOG CHANNEL SELECT
0	0	1	1	*2 CODE SELECT/: *3 CLOCK RATE SELECT
0	1	0	0	*4 LOW-BYTE DATA OUTPUT
0	1	0	1	*4 HIGH-BYTE DATA OUTPUT
0	0	0	X	INHIBIT
			0;	LOW LEVEL X: DON'T CARE HIGH LEVEL

		CHANN	
SEL2	SEL 1	SELO	MPX CHAN.
0	٥	0	СНО
0	0	1	CHI
0	1	0	CH 2
0	1	1	CH 3
1	0	0	CH4
1	0	1	CH5
1	1	0	CH6
1	1	1	CH7

-2 -	DDE SELECT
	CODE SELECT
	BINARY DATA
	2'S COMPLEMENT DATA

#3 CLOCK RATE SELECT					
DEV1	DEV O	CLOCK RATE			
0	0	1			
0	1	1/2			
1	0	1/4			
1	1	1/8			

*4 LOW/HIGH-BYTE DATA								
	DB7	DB 6	D85	DB4	DB3	DB2	DB 1	DB 0
HIGH-BYTE	MSB	2ND	3RD	4TH	5TH	6TH	7TH	втн
LOW- BYTE	9TH	0	0	0	0	0	0	0

SECTION C SPARE PARTS

PARTS INFORMATION

1. Safety Related Component Warning

Components indentified by shading marked with \triangle on the schematic diagrams, exploded views and electrical spare parts list are critical to safe operation. Replace these components with Sony parts whose parts numbers appear as shown in this manual or in service manual supplements published by Sony.

- 2. Replace Parts that are supplied from Sony Parts Center can sometimes have different shape and external appearance than what are actually used in equipment. This is due to "accommodating the improved parts and/or engineering changes" or "standardization of genuine parts."
 - This manual 's exploded view and electrical spare parts lists are indicating the parts numbers of "the standardized genuine parts at present."
 - · Regarding engineering parts and diagrams changes in our engineering department, refer to Sony service bulletins and service manual supplements.
- 3. The parts marked with "S" in the SP column of the exploded views and electrical spare parts list are normally required for routine service work. Orders for parts marked with "O" will be processed, but allow for additional delivery time.
- 4. Item with no parts number and/or no description are not stocked because they are seldom required for routine service.
- 5. Regarding engineering parts changes in our engineering department, refer to SECTION D "CHANGED PARTS".

6. Abbreviation

		REF.NO.	DESCRIPTION	REF.NO.	DESCRIPTION
BT BA	TTERY	F	FUSE	RB, RP	RESISTOR BLOCK
BZ BUZ	ZZER	FB	FERRITE BEAD	RY	RELAY
C CAI	PACITOR	FL	FILTER	RV	VARIABLE RESISTOR
CF CER	RAMIC FILTER	IC	IC	S	SWITCH
CN CO	NNECTOR	L	INDUCTOR	T	TRANSFORMER
CP CO	MBINATION PARTS	LV	VARIABLE INDUCTOR	TH	THERMISTOR
CV VAI	RIABLE CAPACITOR	PL	PILOT LAMP	TM	TIMER
D DIO	DDE	Q	TRANSISTOR	VDR	VARISTOR
DL DEI	LAY LINE	R	RESISTOR	X	OSCILLATOR

All capacitors are in micro farads unless otherwise specified.

All inductors are in micro henries unless otherwise specified.

All resistors are in ohms.

EXPLODED VIEW

RCP-3730/3731

```
SP Description
                       Part No.
No.
                      A-7515-207-A 0 MOUNTED CIRCUIT BOARD, SW-402
A-7515-208-A 0 MOUNTED CIRCUIT BOARD, MPU-56
A-7602-074-A 0 LCD ASSY
A-7612-369-A 0 JOY STICK ASSY (RCP-3730 ONLY)
X-2141-066-1 0 PANEL ASSY (D2), CONTROL
                                                                                                                                                                                                                       2-356-548-01 o COVER (1), LED (RCP-3731 ONLY)
2-356-549-01 o COVER (2), LED (RCP-3731 ONLY)
2-356-558-01 o TUBE, FIXED, VR (RCP-3730 ONLY)
2-356-559-01 o TUBE, ADJUSTMENT (RCP-3730 ONLY)
2-356-560-01 o TUBE, COVER (RCP-3730 ONLY)
   1
2
3
                                                                                                                                                                                                 42
43
                                                                                                                                                                                                  44
45
    4
5
                       X-2270-601-0 s KNOB ASSY (RCP-3731 ONLY)
X-3165-071-1 s KNOB (SMALL) ASSY
X-3651-342-0 s KNOB ASSY CONTROL (RCP-3731 ONLY)
1-224-981-00 s RES, VAR, CERMET 5K "IRIS"
"MASTER BLACK" (RCP-3731 ONLY)
1-224-981-31 s RES, VAR, CERMET 5K
"MASTER BLACK" (RCP-3730 ONLY)
                                                                                                                                                                                                                       2-356-561-01 o SHAFT, FIXED, COVER (RCP-3730 ONLY)
2-356-571-01 o ESCUTCHEON, LEVER (RCP-3730 ONLY)
3-165-439-01 o PLATE (3), FIXED, RV
3-165-440-01 o COVER, LCD
3-165-441-01 o COVER (3), LED
                                                                                                                                                                                                  46
                                                                                                                                                                                                 48
49
50
 10
                                                                                                                                                                                                                       3-165-446-01 o CHASSIS (B3), SUB
3-165-447-01 o PANEL (B3), CONTROL
3-165-448-01 o COVER (B3)
3-306-006-00 s CUSHION, MOTOR (RCP-3730 ONLY)
3-657-810-00 s BEARING (LF1280ZZ), BALL
(RCP-3730 ONLY)
                       1-230-817-11 s RES, VAR, CARBON 5K "IRIS"


(RCP-3730 ONLY)

1-237-955-11 s RES, VAR, CARBON 10K "SENSE"


1-238-293-11 s RES, VAR, CARBON 10K "COARSE"


1-466-102-11 s ENCODER, ROTARY
"BLUE" "RED" "GREEN"
                                                                                                                                                                                                  52
53
54
 11
  12
  13
                                                                                                                                                                                                                       3-657-864-00 o SUPPORT, DP
3-672-251-00 s RING (M4), O (RCP-3730 ONLY)
3-692-963-01 s WASHER (A) (RCP-3730 ONLY)
3-701-444-21 s WASHER, 6 (RCP-3730 ONLY)
3-701-505-00 s SET SCREW, DOUBLE POINT 3X3
                        1-561-795-00 s SOCKET, CONNECTOR 6P
                                                                                                                                                                                                  56
  15
                                                                                                                                                                                                  57
58
59
                         1-564-968-11 s CONNECTOR, MULTI (SQUARE) 16P
1-570-504-11 s SWITCH, MICRO "LOCK"
  16
17
                                                                                                                                      (RCP-3730 ONLY)
                                                                                                                                                                                                  60
                       1-632-787-11 0 PRINTED CIRCUIT BOARD, IR-12 (RCP-3730 ONLY)
1-632-788-11 0 PRINTED CIRCUIT BOARD, DSP-27 (RCP-3730 ONLY)
1-632-789-11 0 PRINTED CIRCUIT BOARD, DSP-28 (RCP-3731 ONLY)
  18
                                                                                                                                                                                                                       3-701-510-00 s SET SCREW, DOUBLE POINT 4X4
(RCP-3730 ONLY)
3-712-653-01 s NUT (M8), TUBE (RCP-3730 ONLY)
3-712-786-01 s DAMPER, OIL
4-812-554-00 s WASHER (RCP-3730 ONLY)
4-870-261-00 o SUPPORT (RCP-3730 ONLY)
                                                                                                                                                                                                  61
  19
                                                                                                                                                                                                  62
                                                                                                                                                                                                  63
  20
                                                                                                                                                                                                  64
                                                                                                                                                                                                  65
                         1-636-955-11 o LED-112
2-118-880-01 o CAP
2-118-881-01 o WHEEL
2-141-006-01 o GUARD (SQUARE 6), SWITCH
2-141-013-01 o GEAR (A), IRIS (RCP-3730 ONLY)
  21
22
23
24
25
                         2-141-014-01 o GEAR (B), IRIS (RCP-3730 ONLY)
2-141-017-01 s KNOB, RV
2-141-027-01 o CHASSIS (D2), SUB
2-141-029-01 o BRACKET (2), RACK
2-141-030-01 o COVER (J2), LED (RCP-3730 ONLY)
  26
27
28
29
30
                         2-141-031-01 o INSULATOR (2)
2-141-036-01 o PANEL (J2), CONTROL
                        2-141-038-01 o CHASSIS (J2), SUB (RCP-3730 ONLY)
2-141-039-01 o COVER (S)
2-249-395-02 o NUT, PLATE, 4P
    35
                         2-270-659-00 s MARKER (B)
2-270-660-00 s MARKER (R)
2-280-622-41 o SUPPORT (M3), HEXAGON
2-284-901-00 s MARKER (G)
   36
37
38
39
                          2-356-547-01 o TUBE, LEVER FIXED (RCP-3730 ONLY)
```


EXPLODED VIEW





SCREWS

















TOT:	
⊜ €	
7-685-	00-00
SIZE	Parts No.
2 × 4	102-19
2 × 5	103-19
2 x 6 2 x 8	104-19
2 x 8 2 x 10	105-19 106-19
2 x 10	107-19
2.6 x 4	131-19
2.6 x 5	132-19
2.6 x 6	133-19
2.6 x 8	134-19
2.6 x 10	135-19
2.6 x 12	136-19
2.6 x 14	137-19 138-19
2.6 x 16	136-19
3 × 5	144-19
3 x 6	145-19
3 × 8	146-19
3 x 10 3 x 12	147-19 148-19
3 x 12	149-19
3 x 14	150-19
3 × 18	100 10
3 × 20	151-19
3 × 25	152-19
3 × 30	153-19
3 x 35	154-19
3 × 40	155-19
3 × 58	
4 × 6	158-19
4 x 8	159-19
4 × 10	160-19
4 x 12	161-19
4 x 14 4 x 16	162-19
4 x 16 4 x 20	163-19 164-19
4 × 25	165-19
4 × 30	166-19
4 x 35	167-19
1	I

	٠		
DSP-27 BOARD	MPU-56 H		- 144 A - 1 - 1 - 1
Ref. No. or Q'ty Part No. SP Description	Ref. No. or Q'ty	Part No. SP	Description
4pcs 1-563-521-11 o CONNECTOR, 20P, FEMALE 1-632-788-11 o PRINTED CIRCUIT BOARD, DSP-27	1pc	gisteli.	MOUNTED CIRCUIT BOARD, MPU-56
CN1 1-566-405-11 o CONNECTOR, 30P, MALE CN2 1-506-471-11 o CONNECTOR, 6P, MALE CN3 1-506-469-11 o CONNECTOR, 4P, MALE	C1 C2 C3 C4	1-131-345-00 s 1-164-232-11 s	CERAMIC, CHIP 0.01uF 10% 50V TANTALUM 0.47uF 10% 35V CERAMIC, CHIP 0.01uF 10% 50V CERAMIC, CHIP 0.01uF 10% 50V CERAMIC, CHIP 0.01uF 10% 50V
D1 8-719-939-53 s DIODE LB-203ML D2 8-719-948-06 s DIODE LB-202ML D3 8-719-938-68 s GL-3HY8	C5 C6 C7	1-164-232-11 s 1-164-232-11 s	CERAMIC, CHIP 0.01uF 10% 50V CERAMIC, CHIP 0.01uF 10% 50V
\$1 1-554-048-00 s SWITCH WITH LED, PUSH \$2 1-554-048-00 s SWITCH WITH LED, PUSH	C8 C9 C10	1-164-232-11 s 1-164-232-11 s	CERAMIC, CHIP 0.01uF 10% 50V CERAMIC, CHIP 0.01uF 10% 50V CERAMIC, CHIP 0.01uF 10% 50V
	C11 C12 C13 C14 C15	1-164-232-11 s 1-164-232-11 s	CERAMIC, CHIP 0.01uF 10% 50V CERAMIC, CHIP 0.01uF 10% 50V CERAMIC, CHIP 0.01uF 10% 50V CERAMIC, CHIP 0.01uF 10% 50V CERAMIC, CHIP 0.01uF 10% 50V
DSP-28 BOARD	C16		CERAMIC, CHIP 0.01uF 10% 50V CERAMIC, CHIP 0.01uF 10% 50V
Ref. No. or Q'ty Part No. SP Description 4pcs 1-563-521-11 o CONNECTOR, 20P, FEMALE	C17 C18 C19 C20	1-126-949-11 s 1-164-232-11 s	CERAMIC, CHIP 0.01uF 10% 50V ELECT 220uF 20% 35V CERAMIC, CHIP 0.01uF 10% 50V CERAMIC, CHIP 0.01uF 10% 50V
4pcs 1-563-521-11 o CONNECTOR, 20P, FEMALE 1pc 1-632-789-11 o PRINTED CIRCUIT BOARD, DSP-28 1pc 2-141-017-01 s KNOB, RV 1pc 7-621-734-09 s SET-SCT, HEX. 2.6X3	C21 C22		CERAMIC, CHIP 0.01uF 10% 50V CERAMIC, CHIP 0.01uF 10% 50V CERAMIC, CHIP 0.01uF 10% 50V CERAMIC, CHIP 0.01uF 10% 50V
CN1 1-566-405-11 o CONNECTOR, 30P, MALE CN2 1-506-469-11 o CONNECTOR, 4P, MALE	C23 C24 C25	1-164-232-11 S	CERAMIC, CHIP 0.01uF 10% 50V CERAMIC, CHIP 0.01uF 10% 50V CERAMIC, CHIP 0.01uF 10% 50V
D1 8-719-939-53 s DIODE LB-203ML D2 8-719-948-06 s DIODE LB-202ML D3 8-719-938-68 s GL-3HY8 RV1 1-238-293-11 s RES, VAR, CARBON 10K	C26 C27 C28 C29	1-127-515-11 s 1-164-232-11 s	CERAMIC, CHIP 0.01uF 10% 50V ELECTSOLID 20 10V CERAMIC, CHIP 0.01uF 10% 50V ELECT 2200uF 20% 10V
		1-163-038-00 s	CERAMIC, CHIP 0.1uF 25V
\$1	C31 C32 C33 C34 C35	1-163-038-00 s 1-124-443-00 s 1-163-263-11 s	TANTALUM 1uF 10% 35V CERAMIC, CHIP 0.1uF 25V ELECT 100uF 20% 10V CERAMIC 330PF 5% 50V CERAMIC, CHIP 15PF 5% 50V
	C36 C37 C38 C39	1-124-472-11 s 1-161-900-11 s	CERAMIC, CHIP 15PF 5% 50V ELECT 470uF 20% 10V ELECT 470uF 20% 10V CERAMIC 1uF 50V
IR-27 BOARD	C41 C42		TANTALUM 47uF 10% 10V TANTALUM 47uF 10% 10V
Ref. No. or Q'ty Part No. SP Description	C43 C44	1-131-381-00 s 1-131-381-00 s	TANTALUM 47uF 10% 10V TANTALUM 47uF 10% 10V
1pc 1-632-787-11 o PRINTED CIRCUIT BOARD, IR-12 1pc 2-141-017-01 s KNOB, RV 1pc 7-621-734-09 s SET-SCT,HEX. 2.6X3	C45 C46	1-131-381-00 s 1-163-038-00 s	TANTALUM 47uf 10% 10V CERAMIC, CHIP 0.1uf 25V
RV1 1-238-293-11 s RES, VAR, CARBON 10K	C47		CERAMIC, CHIP 0.01uF 10% 50V
RV2 1-237-955-11 s RES, VAR, CARBON 10K	CN1 CN2 CN3 CN4 CN5	1-566-401-11 o 1-566-398-11 o 1-506-473-11 o	CONNECTOR, 30P, MALE CONNECTOR, 22P, MALE CONNECTOR, 16P, MALE CONNECTOR, 8P, MALE CONNECTOR, 4P, MALE
	CN6 CN7 CN8	1-506-469-11 o	CONNECTOR, 4P, MALE CONNECTOR, 4P, MALE CONNECTOR, 8P, MALE
	CNI12	1-526-659-00 o	SOCKET, IC (DP) 28P

```
(MPU-56 BOARD)
 (MPU-56 BOARD)
                                                                                                                                                                                                           Ref. No. or Q'ty Part No.
Ref. No. or Q'ty Part No.
                                                                                                                                                                                                                                                                       SP Description
                                                           SP Description
                                                                                                                                                                                                                                       8-729-920-34 s TRANSISTOR DTC143XK
8-729-271-22 s TRANSISTOR 2SC2712-G
8-729-216-22 s TRANSISTOR 2SA1162
8-729-906-45 s TRANSISTOR DTA143XK
8-729-271-22 s TRANSISTOR 2SC2712-G
                            8-719-800-76 s DIODE 1SS226
                                                                                                                                                                                                           Q9
Q10
Q11
Q12
 ĎŽ
 \bar{D}\bar{3}
 Ďŝ
                            8-719-800-76 s DIODE 1SS226
                                                                                                                                                                                                                                        1-216-089-00 s METAL, CHIP 47K 5% 1/10W
1-216-097-00 s METAL, CHIP 100K 5% 1/10W
1-216-057-00 s METAL, CHIP 2.2K 5% 1/10W
1-216-085-00 s METAL, CHIP 33K 5% 1/10W
1-216-079-00 s METAL, CHIP 18K 5% 1/10W
 D6
 D7
                                                                                                                                                                                                           \tilde{R}\bar{3}
 D8
                                                                                                                                                                                                           R4
 D9
                                                                                                                                                                                                           Ř5
                             8-719-800-76 s DIODE 1SS226
8-719-800-76 s DIODE 1SS226
8-719-800-76 s DIODE 1SS226
8-719-800-76 s DIODE 1SS226
                                                                                                                                                                                                                                        1-216-085-00 s METAL, CHIP 33K 5% 1/10W 1-216-085-00 s METAL, CHIP 33K 5% 1/10W 1-216-624-11 s METAL, CHIP 75 0.5% 1/10W 1-216-624-11 s METAL, CHIP 75 0.5% 1/10W 1-216-085-00 s METAL, CHIP 33K 5% 1/10W
 \overline{D12}
                                                                                                                                                                                                            R7
                                                                                                                                                                                                            RR
  \bar{D}\bar{1}\bar{3}
  D14
                              8-719-800-76 s DIODE 1SS226
                                                                                                                                                                                                            R10
                                                                                                                                                                                                                                        1-216-085-00 s METAL, CHIP 33K 5% 1/10W 1-216-085-00 s METAL, CHIP 33K 5% 1/10W
                              8-719-800-76 s DIODE 1SS226
8-719-800-76 s DIODE 1SS226
8-719-106-70 s DIODE RD12M-B1
  D16
                                                                                                                                                                                                           R12
R13
  Ď17
                                                                                                                                                                                                            R15
                              1-535-178-00 s BEAD, FERRITE
  FB1
                                                                                                                                                                                                                                        1-216-085-00 s METAL, CHIP 33K 5% 1/10W 1-216-085-00 s METAL, CHIP 33K 5% 1/10W
                              8-759-925-74 s IC SN74HC04NS
8-759-918-65 s IC TL7700CPS
8-759-925-08 s IC MC74HC86F
8-759-971-23 s IC MSM80C49-757GS-K
8-759-925-85 s IC SN74HC32NS
                                                                                                                                                                                                            R16
  IC2
IC3
IC4
                                                                                                                                                                                                            R17
                                                                                                                                                                                                            R18
                                                                                                                                                                                                            R19
                                                                                                                                                                                                            R20
                                                                                                                                                                                                                                        1-216-025-00 s METAL, CHIP 100 5% 1/10W 1-216-085-00 s METAL, CHIP 33K 5% 1/10W
                               8-759-205-37 s IC TC74HC574F
8-759-926-49 s IC SN74HC245NS'
8-759-926-23 s IC SN74HC163NS
8-759-321-84 s IC HD64180ZF8
8-759-926-11 s IC SN74HC138NS
  IC6
IC7
IC8
IC9
                                                                                                                                                                                                            R22
R23
                                                                                                                                                                                                             R24
                                                                                                                                                                                                             R25
   ĪC10
                               8-752-330-98 s IC CXK5864BM-10L
8-759-748-46 s IC TMS27C256-20JL
8-759-106-58 s IC UPD7004C
8-759-112-63 s IC UPD4701AC
8-759-112-63 s IC UPD4701AC
                                                                                                                                                                                                                                        1-216-085-00 s METAL, CHIP 33K 5% 1/10W 1-216-085-00 s METAL, CHIP 33K 5% 1/10W
                                                                                                                                                                                                            R26
   IC12
IC13
IC14
                                                                                                                                                                                                             R27
                                                                                                                                                                                                             R28
    IC15
                                                                                                                                                                                                                                        1-216-085-00 s METAL, CHIP 33K 5% 1/10W 1-216-085-00 s METAL, CHIP 33K 5% 1/10W
                               8-759-938-68 s IC CXD1095Q
8-759-234-67 s IC TMP82C79M-2
1-466-254-11 s CONVERTER UNIT, DC-DC
8-759-925-72 s IC SN74HC02NS
8-759-925-72 s IC SN74HC02NS
                                                                                                                                                                                                             R32
    IC17
                                                                                                                                                                                                             R33
    IC18
                                                                                                                                                                                                             R34
    IC19
                                                                                                                                                                                                             R35
    ĪC20
                                                                                                                                                                                                                                        1-216-085-00 s METAL, CHIP 33K 5% 1/10W 1-216-085-00 s METAL, CHIP 33K 5% 1/10W
                               8-759-300-71 s IC MC14053BF
8-759-231-32 s IC TC7S00F
8-759-234-10 s IC TC7S32F
8-759-720-57 s IC H758C65FP-25
    IC21
    IC22
IC23
IC24
IC25
                                                                                                                                                                                                             R37
                                                                                                                                                                                                             R38
                                                                                                                                                                                                             R39
                                 8-759-234-10 s IC TC7S32F
                                                                                                                                                                                                             R40
                                                                                                                                                                                                                                        1-216-085-00 s METAL, CHIP 33K 5% 1/10W 1-216-085-00 s METAL, CHIP 33K 5% 1/10W
                                8-759-230-43 s IC TC7S04F
    IC26
                                                                                                                                                                                                            R42
                                                                                                                                                                                                            R43
R44
                                1-216-295-00 s METAL, CHIP 0-0HM
    JR1
                                                                                                                                                                                                            R45
                                1-410-948-11 s INDUCTOR 100uH
    L1
                                                                                                                                                                                                                                        1-216-085-00 s METAL, CHIP 33K 5% 1/10W 1-216-085-00 s METAL, CHIP 33K 5% 1/10W 1-216-085-00 s METAL, CHIP 33K 5% 1/10W 1-216-057-00 s METAL, CHIP 2.2K 5% 1/10W 1-216-105-00 s METAL, CHIP 220K 5% 1/10W
    PH1
                                8-719-820-86 s DIODE TLP112
                                                                                                                                                                                                            R47
                                8-729-271-22 s TRANSISTOR 2SC2712-G
8-729-216-22 s TRANSISTOR 2SA1162
8-729-216-22 s TRANSISTOR 2SA1162
8-729-271-22 s TRANSISTOR 2SC2712-G
                                                                                                                                                                                                            R48
                                                                                                                                                                                                             R49
    Q2
Q3
Q4
Q5
                                                                                                                                                                                                                                        1-216-017-00 s METAL, CHIP 47 5% 1/10W
1-216-085-00 s METAL, CHIP 33K 5% 1/10W
1-216-025-00 s METAL, CHIP 100 5% 1/10W
1-216-065-00 s METAL, CHIP 47K 5% 1/10W
                                 8-729-271-22 s TRANSISTOR 2SC2712-G
                                 8-729-271-22 s TRANSISTOR 2SC2712-G
8-729-920-34 s TRANSISTOR DTC143XK
                                                                                                                                                                                                                                         1-216-065-00 s METAL,
                                                                                                                                                                                                                                                                                                             CHIP 4.7K 5% 1/10W
```

(MPU-56 BOARD)

```
SW-402 BOARD
 Ref. No. or Q'ty Part No.
                                                               SP Description
                           A-7515-207-A o MOUNTED CIRCUIT BOARD, SW-402
1-563-521-11 o CONNECTOR, 20P, FEMALE
1-566-475-11 o PIN, SOCKET 3P
1-636-955-11 o PRINTED CIRCUIT BOARD, LED-112
 1pc
 5pcs
  2pcs
                           1-164-232-11 s CERAMIC, CHIP 0.01uF 10% 50V 1-164-232-11 s CERAMIC, CHIP 0.01uF 10% 50V
 C1
C2
C3
C4
                           1-164-232-11 s CERAMIC, CHIP 0.01uF 10% 50V 1-164-232-11 s CERAMIC, CHIP 0.01uF 10% 50V
                           1-164-232-11 s CERAMIC, CHIP 0.01uF 10% 50V 1-135-161-21 s TANTALUM, CHIP 22uF 10% 10V 1-135-161-21 s TANTALUM, CHIP 22uF 10% 10V 1-126-157-11 s ELECT 10uF 20% 16V
 C11
 C12
 \tilde{C}\bar{1}\bar{3}
 C14
                           1-566-405-11 o CONNECTOR, 30P, MALE
1-566-401-11 o CONNECTOR, 22P, MALE
1-566-405-11 o CONNECTOR, 30P, MALE
1-506-469-11 o CONNECTOR, 4P, MALE
1-566-402-11 o CONNECTOR, 24P, MALE
 CN1
 ČN2
 CN3
CN4
 CN5
                           D2
 D3
 D5
                           8-719-400-18 s DIODE MA152WK
 D6
 D7
 D8
 D9
 D10
                            8-719-400-18 s DIODE MA152WK
                           8-719-400-18 s DIODE MA152WK
8-719-400-18 s DIODE MA152WK
8-719-400-18 s DIODE MA152WK
8-719-400-18 s DIODE MA152WK
 D13
 Dī5
                         ĎĨŽ
 D18
 D19
D20
                         8-719-400-18 s DIODE MA152WK
8-719-400-18 s DIODE MA152WK
8-719-400-18 s DIODE MA152WK
8-719-400-18 s DIODE MA152WK
8-719-948-07 s LED LD-001MG, GRN
D22
D23
D24
D25
                         8-719-800-26 s TLUG164
8-719-914-40 s DIODE SLT-35MG3
8-719-987-52 s DIODE SLT-35DU
8-719-939-53 s DIODE LB-203ML
8-719-939-53 s DIODE LB-203ML
D26
D27
D28
D29
D30
                          8-719-939-53 s DIODE LB-203ML
8-719-800-76 s DIODE 185226
D31
\bar{D}3\bar{2}
                         8-759-926-80 s IC SN74HC573NS
8-759-926-80 s IC SN74HC573NS
8-759-926-80 s IC SN74HC573NS
```

(SW-402 BOARD)		(SW-402	BOARD)
Ref. No. or Q'ty Part No. SP Description		Ref. No. or Q'ty	Part No. SP Description
IC4 8-759-926-80 s IC SN74HC573NS IC5 8-759-926-80 s IC SN74HC573NS IC6 8-759-926-80 s IC SN74HC573NS IC7 8-759-926-80 s IC SN74HC573NS IC8 8-759-926-80 s IC SN74HC573NS		Q47 Q48 Q49 Q50 Q51	8-729-920-34 s TRANSISTOR DTC143XK 8-729-920-34 s TRANSISTOR DTC143XK 8-729-920-34 s TRANSISTOR DTC143XK 8-729-920-34 s TRANSISTOR DTC143XK 8-729-920-34 s TRANSISTOR DTC143XK
IC9 8-759-926-11 s IC SN74HC138NS IC10 8-759-926-42 s IC SN74HC238NS IC11 8-759-926-42 s IC SN74HC238NS IC12 8-759-230-43 s IC TC7S04F		Q52 Q53 Q54 Q55 Q56	8-729-920-34 s TRANSISTOR DTC143XK 8-729-920-34 s TRANSISTOR DTC143XK 8-729-920-34 s TRANSISTOR DTC143XK 8-729-920-34 s TRANSISTOR DTC143XK 8-729-920-34 s TRANSISTOR DTC143XK
L1 1-410-517-11 s INDUCTOR 47uH L2 1-410-517-11 s INDUCTOR 47uH L3 1-410-517-11 s INDUCTOR 47uH		Q57 Q58	8-729-920-34 s TRANSISTOR DTC143XK 8-729-906-45 s TRANSISTOR DTA143XK 8-729-906-45 s TRANSISTOR DTA143XK
Q1 8-729-920-34 S TRANSISTOR DTC143XK Q2 8-729-920-34 S TRANSISTOR DTC143XK Q3 8-729-920-34 S TRANSISTOR DTC143XK Q4 8-729-920-34 S TRANSISTOR DTC143XK		Q60 Q61	8-729-906-45 s TRANSISTOR DTA143XK 8-729-906-45 s TRANSISTOR DTA143XK
Q1 8-729-920-34 S TRANSISTOR DTC143XK Q2 8-729-920-34 S TRANSISTOR DTC143XK Q3 8-729-920-34 S TRANSISTOR DTC143XK Q4 8-729-920-34 S TRANSISTOR DTC143XK Q5 8-729-920-34 S TRANSISTOR DTC143XK		Q62 Q63 Q64	8-729-906-45 s TRANSISTOR DTA143XK 8-729-906-45 s TRANSISTOR DTA143XK 8-729-906-45 s TRANSISTOR DTA143XK
Q6 8-729-920-34 s TRANSISTOR DTC143XK Q7 8-729-920-34 s TRANSISTOR DTC143XK Q8 8-729-920-34 s TRANSISTOR DTC143XK Q9 8-729-920-34 s TRANSISTOR DTC143XK Q10 8-729-920-34 s TRANSISTOR DTC143XK		065 066	8-729-906-45 s TRANSISTOR DTA143XK 8-729-159-64 s TRANSISTOR 2SD596
Öğ 8-729-920-34 s TRANSISTOR DTC143XK Q10 8-729-920-34 s TRANSISTOR DTC143XK		Q67 Q68 Q69	8-729-159-64 s TRANSISTOR 2SD596 8-729-159-64 s TRANSISTOR 2SD596 8-729-159-64 s TRANSISTOR 2SD596
011 8-729-920-34 S TRANSISTOR DTC143XK 012 8-729-920-34 S TRANSISTOR DTC143XK 013 8-729-920-34 S TRANSISTOR DTC143XK 014 8-729-920-34 S TRANSISTOR DTC143XK		Q70 Q71	8-729-159-64 s TRANSISTOR 2SD596 8-729-159-64 s TRANSISTOR 2SD596
		072 073 074 075 076	8-729-159-64 s TRANSISTOR 2SD596
016 8-729-920-34 S TRANSISTOR DTC143XK 017 8-729-920-34 S TRANSISTOR DTC143XK 018 8-729-920-34 S TRANSISTOR DTC143XK	•		8-729-159-64 s TRANSISTOR 2SD596 8-729-159-64 s TRANSISTOR 2SD596
019 8-729-920-34 S TRANSISTOR DTC143XK 020 8-729-920-34 S TRANSISTOR DTC143XK		Q77 Q78 Q79 Q80	8-729-159-64 s TRANSISTOR 2SD596 8-729-159-64 s TRANSISTOR 2SD596 8-729-159-64 s TRANSISTOR 2SD596 8-729-920-34 s TRANSISTOR DTC143XK
Q21 8-729-920-34 S TRANSISTOR DTC143XK Q22 8-729-920-34 S TRANSISTOR DTC143XK Q23 8-729-920-34 S TRANSISTOR DTC143XK Q24 8-729-920-34 S TRANSISTOR DTC143XK Q25 8-729-920-34 S TRANSISTOR DTC143XK Q25 8-729-920-34 S TRANSISTOR DTC143XK		R1 R2 R3 R4	1-216-025-00 s METAL, CHIP 100 5% 1/10W 1-216-049-00 s METAL, CHIP 1K 5% 1/10W 1-216-029-00 s METAL, CHIP 150 5% 1/10W 1-216-029-00 s METAL, CHIP 150 5% 1/10W
Q26 8-729-920-34 S TRANSISTOR DTC143XK Q27 8-729-920-34 S TRANSISTOR DTC143XK		R5	1-216-029-00 s METAL, CHIP 150 5% 1/10W 1-216-029-00 s METAL, CHIP 150 5% 1/10W
028 8-729-920-34 s TRANSISTOR DTC143XK 029 8-729-920-34 s TRANSISTOR DTC143XK 030 8-729-920-34 s TRANSISTOR DTC143XK	•	R6 R7 R8 R9	1-216-017-00 s METAL, CHIP 47 5% 1/10W 1-216-023-00 s METAL, CHIP 82 5% 1/10W 1-216-029-00 s METAL, CHIP 150 5% 1/10W
Q31 8-729-920-34 S TRANSISTOR DTC143XK Q32 8-729-920-34 S TRANSISTOR DTC143XK Q33 8-729-920-34 S TRANSISTOR DTC143XK		R10 R11	1-216-029-00 s METAL, CHIP 150 5% 1/10W 1-216-029-00 s METAL, CHIP 150 5% 1/10W
Q33 8-729-920-34 S TRANSISTOR DTC143XK Q34 8-729-920-34 S TRANSISTOR DTC143XK Q35 8-729-920-34 S TRANSISTOR DTC143XK		R12 R13 R14	1-216-041-00 s METAL, CHIP 470 5% 1/10W 1-216-029-00 s METAL, CHIP 150 5% 1/10W 1-216-029-00 s METAL, CHIP 150 5% 1/10W
Q36 8-729-920-34 s TRANSISTOR DTC143XK Q37 8-729-920-34 s TRANSISTOR DTC143XK Q38 8-729-920-34 s TRANSISTOR DTC143XK		R15 R16	1-216-029-00 s METAL, CHIP 150 5% 1/10W 1-216-029-00 s METAL, CHIP 150 5% 1/10W
039 8-729-920-34 S TRANSISTOR DTC143XK Q40 8-729-920-34 S TRANSISTOR DTC143XK		R17 R18 R19	1-216-029-00 s METAL, CHIP 150 5% 1/10W 1-216-029-00 s METAL, CHIP 150 5% 1/10W 1-216-029-00 s METAL, CHIP 150 5% 1/10W
Q41 8-729-920-34 S TRANSISTOR DTC143XK Q42 8-729-920-34 S TRANSISTOR DTC143XK Q43 8-729-920-34 S TRANSISTOR DTC143XK		R20 R21	1-216-029-00 s METAL, CHIP 150 5% 1/10W 1-216-041-00 s METAL. CHIP 470 5% 1/10W
Q44 8-729-920-34 S TRANSISTOR DTC143XK Q45 8-729-920-34 S TRANSISTOR DTC143XK		R22 R23 R24	1-216-037-00 s METAL, CHIP 330 5% 1/10W 1-216-037-00 s METAL, CHIP 330 5% 1/10W 1-216-029-00 s METAL, CHIP 150 5% 1/10W
Q46 8-729-920-34 s TRANSISTOR DTC143XK		R25	1-216-029-00 s METAL, CHIP 150 5% 1/10W

1-216-019-00 s METAL, CHIP 56 5% 1/10W 1-216-019-00 s METAL, CHIP 56 5% 1/10W

1-216-049-00 s METAL, CHIP 1K 5% 1/10W 1-216-049-00 s METAL, CHIP 1K 5% 1/10W 1-216-049-00 s METAL, CHIP 1K 5% 1/10W 1-216-049-00 s METAL, CHIP 1K 5% 1/10W 1-216-049-00 s METAL, CHIP 1K 5% 1/10W

1-216-049-00 s METAL, CHIP 1K 5% 1/10W 1-216-049-00 s METAL, CHIP 1K 5% 1/10W 1-216-049-00 s METAL, CHIP 1K 5% 1/10W 1-216-049-00 s METAL, CHIP 1K 5% 1/10W 1-216-049-00 s METAL, CHIP 1K 5% 1/10W

1-216-049-00 s METAL, CHIP 1K 5% 1/10W 1-216-049-00 s METAL, CHIP 1K 5% 1/10W 1-216-049-00 s METAL, CHIP 1K 5% 1/10W 1-216-049-00 s METAL, CHIP 1K 5% 1/10W 1-216-025-00 s METAL, CHIP 100 5% 1/10W

1-216-025-00 s METAL, CHIP 100 5% 1/10W 1-216-025-00 s METAL, CHIP 100 5% 1/10W 1-216-085-00 s METAL, CHIP 33K 5% 1/10W 1-216-089-00 s METAL, CHIP 47K 5% 1/10W

(SW-402 BOARD)

R60

R62 R63 R64 R65

R67 R68 R69

R71

R72 R73 R74 R75

R78 R80

R81 R82 R83 (SW-402 BOARD)

Ref. No. or Q'ty	Part No. SP Description
R85 R86 R87	1-216-065-00 s METAL, CHIP 4.7K 5% 1/10W 1-216-069-00 s METAL, CHIP 6.8K 5% 1/10W 1-216-109-00 s METAL, CHIP 330K 5% 1/10W
RV1	1-237-955-11 s RES, VAR, CARBON 10K
RV2	1-237-955-11 s RES, VAR, CARBON 10K
\$1	1-554-043-41 s SWITCH, PUSH
\$2	1-554-048-00 s SWITCH WITH LED, PUSH
\$3	1-570-211-11 s SWITCH, PUSH
\$4	1-554-048-00 s SWITCH WITH LED, PUSH
\$5	1-554-048-00 s SWITCH WITH LED, PUSH
\$6	1-570-210-11 s SWITCH, PUSH
\$7	1-570-221-11 s SWITCH, PUSH
\$8	1-554-048-00 s SWITCH WITH LED, PUSH
\$9	1-570-211-11 s SWITCH, PUSH
\$10	1-554-048-00 s SWITCH WITH LED, PUSH
\$11	1-554-048-00 s SWITCH WITH LED, PUSH
\$12	1-554-048-00 s SWITCH WITH LED, PUSH
\$13	1-554-048-00 s SWITCH WITH LED, PUSH
\$14	1-554-048-00 s SWITCH WITH LED, PUSH
\$15	1-554-048-00 s SWITCH WITH LED, PUSH
\$16	1-554-048-00 s SWITCH WITH LED, PUSH
\$17	1-554-048-00 s SWITCH WITH LED, PUSH
\$18	1-570-208-41 s SWITCH, PUSH
\$19	1-570-207-71 s SWITCH, PUSH
\$20	1-570-207-61 s SWITCH, PUSH
S21	1-570-207-51 s SWITCH, PUSH
S22	1-570-207-31 s SWITCH, PUSH
S23	1-570-207-21 s SWITCH, PUSH
S24	1-570-207-11 s SWITCH, PUSH
S25	1-570-208-11 s SWITCH, PUSH
S26	1-570-208-51 s SWITCH, PUSH
S27	1-570-207-71 s SWITCH, PUSH
S28	1-554-048-00 s SWITCH WITH LED, PUSH
S29	1-554-048-00 s SWITCH WITH LED, PUSH
S30	1-570-209-11 s SWITCH, PUSH
S31	1-554-048-00 s SWITCH WITH LED, PUSH
S32	1-570-211-11 s SWITCH, PUSH
S33	1-570-211-11 s SWITCH, PUSH
S35	1-570-209-11 s SWITCH, PUSH
S36	1-554-048-00 s SWITCH WITH LED, PUSH
\$37	1-554-048-00 s SWITCH WITH LED, PUSH
\$38	1-554-048-00 s SWITCH WITH LED, PUSH
\$39	1-554-048-00 s SWITCH WITH LED, PUSH
\$40	1-554-048-00 s SWITCH WITH LED, PUSH
\$41	1-554-048-00 s SWITCH WITH LED, PUSH
S42	1-554-048-00 s SWITCH WITH LED, PUSH

FRAME

Ref. No. or Q'ty Part No. SP Description
1-466-102-11 s ENCODER, ROTARY

CN1 (to DSP-27 board) (FOR RCP-3730) (to DSP-28 board) (FOR RCP-3731) 1-563-867-11 s JACK, PIN 2P, FEMALE 1-563-883-11 o HOUSING, 30P

CN1 (to MPU-56 board) 1-563-869-11 o CONTACT, FEMALE, AWG26-30 1-563-883-11 o HOUSING, 30P

CN1 (to SW-402 board) 1-563-869-11 o CONTACT, FEMALE, AWG26-30 1-563-883-11 o HOUSING, 30P

CN2 (to DSP-27 board) (FOR RCP-3730) 1-562-151-11 o HOUSING, 6P 1-563-088-11 o CONTACT, FEMALE, AWG24-30

CN2 (to DSP-28 board) (FOR RCP-3731) 1-562-149-11 o HOUSING, 4P 1-563-088-11 o CONTACT, FEMALE, AWG24-30

CN2 (to MPU-56 board) 1-563-869-11 o CONTACT, FEMALE, AWG26-30 1-563-879-11 o HOUSING, 22P

CN2 (to SW-402 board) 1-563-869-11 o CONTACT, FEMALE, AWG26-30 1-563-879-11 o HOUSING, 22P

CN3 (to MPU-56 board) 1-563-869-11 o CONTACT, FEMALE, AWG26-30 1-563-876-11 o HOUSING, 16P

CN3 (to SW-402 board) 1-563-867-11 s JACK, PIN 2P, FEMALE 1-563-883-11 o HOUSING, 30P

CN4 (to SW-402 board) 1-562-149-11 o HOUSING, 4P 1-563-088-11 o CONTACT, FEMALE, AWG24-30

CN101 1-564-968-11 s CONNECTOR, 16P FEMALE

CN201 1-561-795-00 s SOCKET 6P, FEMALE

RV101 1-230-817-11 s RES, VAR, CARBON 5K "IRIS"
(FOR RCP-3730)
1-244-981-00 s RES, VAR, METAL 5K "IRIS"
(FOR RCP-3731)

RV102 1-224-981-31 s RES, VAR, METAL 5K "MASTER BLACK" (FOR RCP-3730) 1-244-981-00 s RES, VAR, METAL 5K "MASTER BLACK" (FOR RCP-3731)

\$101 1-570-504-11 s SWITCH, MICRO "PREVIEW"

PACKING MATERIALS & SUPPLIED ACCESSORIES

Ref. No. or Q'ty Part No. SP Description

1pc 1-560-691-11 s PLUG 6P, MALE 2pcs 1-564-970-11 s CONNECTOR, MULTI (SQUARE) 16P, FEMA 2pcs 2-141-029-01 o BRACKET (2), RACK 1pc 2-355-375-01 o PLATE, NUMBER